

USER'S MANUAL

FOR

TTG-7000 TCAS\TRANSPONDER

RF GENERATOR

1. OVERVIEW	5
2. HARDWARE	8
3. TOUCHSCREEN APPLICATION	12
3.1. MAIN MENU	12
3.1.1. SYSTEM MENU	20
3.1.1.1. Software Update Menu	22
3.1.1.2. Network Connections Menu	24
3.1.1.3. 429 Configuration Menu	27
3.1.2. TCAS MAIN MENU	29
3.1.2.1. TCAS Settings Menu	31
3.1.2.2. Own Aircraft Menu	34
3.1.2.3. TCAS Receiver Menu	37
3.1.2.3.1. TCAS Receiver Filtered Masked Menu	41
3.1.2.3.2. TCAS Receiver Highlight Masked Menu	43
3.1.2.4. TCAS Transmitter Menu	45
3.1.2.4.1. RTCA/DO-260 Tests	46
3.1.2.4.2. Block Transmission	60
3.1.2.5. TCAS Scenario Menu	64
3.1.2.5.1. Static Mode S TCAS Only Definition Menu	68
3.1.2.5.1.1. Coordination Message Menu	71
3.1.2.5.1.2. Broadcast Message	74
3.1.2.5.1.3. Coordination Replies (DF16 Replies)	77
3.1.2.5.1.4. UF0 Messages	79
3.1.2.5.2. Dynamic Mode S TCAS Only Definition Menu	81
3.1.2.5.3. Static Mode C Definition Menu	84
3.1.2.5.4. Dynamic Mode C Definition Menu	86
3.1.2.5.5. Static Mode S Extended Definition Menu	89
3.1.2.5.5.1. Mode S Squitter Definition	92
3.1.2.5.5.2. Position Squitter Definition Menu	93
3.1.2.5.5.3. Velocity Squitter Definition Menu	94
3.1.2.5.5.4. Ident Squitter Definition Menu	96
3.1.2.5.5.5. BDS Register Definition Menu	98
3.1.2.5.6. Dynamic Mode S Extended Definition Menu	99
3.1.2.5.7. Static TIS-B Definition Menu	103
3.1.2.5.8. Dynamic TIS-B Definition Menu	106
3.1.2.5.9. Static ADS-R Definition Menu	109
3.1.2.5.10. Dynamic ADS-R Definition Menu	112

3.1.2.5.11.	TCAS Display Menu	115
3.1.2.5.12.	TCAS Ground Station Menu	117
3.1.2.5.13.	TCAS ATCRBS Pulse Information Menu	120
3.1.2.5.14.	TCAS Mode S Pulse Information Menu	122
3.1.2.5.15.	TCAS Video Blocks Menu	124
3.1.2.6.	TCAS ATE Line Menu	130
3.1.2.7.	TCAS Chamber Mode Menu	132
3.1.2.8.	Measurement Menu	135
3.1.3.	TRANSPONDER MENU	139
3.1.3.1.	Transponder Settings	140
3.1.3.2.	Transponder Test (Single Interrogation	142
3.1.3.3.	Transponder Mode A Menu	145
3.1.3.4.	Transponder Mode C Menu	147
3.1.3.5.	Transponder Mode A All-Call Menu	149
3.1.3.6.	Transponder Mode C All-Call Menu	151
3.1.3.7.	Transponder Mode A/Mode S All-Call Menu	153
3.1.3.8.	Transponder Mode C/Mode S All-Call Menu	155
3.1.3.9.	Transponder Mode S Menu	157
3.1.3.10.	Transponder Test (Double Interrogation Mode)	159
3.1.4	UAT MENU	163
3.1.4.1.	UAT Settings	164
3.1.4.2.	UAT Receiver Menu	166
3.1.4.3	UAT Receiving Station Menu	168
3.1.4.3.	UAT Scenario Menu	170
3.1.4.4.1	UAT Target Definition Menu	172
3.2.	HOW TO ...	180
3.2.1.	HOW TO CHANGE GPIB ADDRESS	180
3.2.2.	HOW TO CHANGE TRANSMITTER FREQUENCY	180
3.2.3.	HOW TO SET A SCOPE OUTPUT	180
3.2.4.	HOW TO PROGRAM DSP SOFTWARE OR FPGA FIRMWARE	180
3.2.5.	HOW TO INSTALL THE TTG-7000C RF AMPLIFIER	181
3.2.6.	HOW TO ENTER OWN AIRCRAFT INFORMATION	181
3.2.7.	HOW TO SETUP A STATIC ATCRBS INTRUDER	181
3.2.8.	HOW TO SETUP A DYNAMIC ATCRBS INTRUDER	183
3.2.9.	HOW TO SETUP A STATIC MODE S INTRUDER	184
3.2.10.	HOW TO SETUP A DYNAMIC MODE S INTRUDER	186
3.2.11.	HOW TO SETUP A STATIC MODE S EXTENDED INTRUDER	187
3.2.12.	HOW TO SETUP A DYNAMIC MODE S EXTENDED INTRUDER	189

4. REMOTE CONNECTION (VNC)	192
-----------------------------------	------------

1. Overview

The TTG-7000 TCAS\Transponder RF Generator is a test set that can be used to perform RF test of a TCAS, Transponder or UAT system. The TTG-7000 contains two Receivers (Top/Bottom), six Transmitters (6 with pulse modulation capability and three with BPSK capability for UF interrogations), and an Antenna Simulator.

The TTG-7000 was designed to allow operators to perform most DO-185, DO-181, DO-260, and DO-300 tests.

The TTG-7000 has the capability of simulating ATCRBS, Mode S Only, Mode S Extended (ADS-B), and ADS-B Only (DF18) aircrafts. The test set can simulate up to 32 dynamic intruders and 568 static intruders.

The TTG-7000 can be controlled from the front panel touch screen display or via commands from USB, GPIB, or TCP/IP.

The TTG-7000 test set performs special software applications not shown in this document that are Customer specific.

TTG-7000 Specifications	
<u>Transmitter Specification:</u>	
Frequency:	
Range:	962 to 1213 MHz
Resolution:	100 KHz
Accuracy:	+/- 10 KHz
Power:	
Range:	-20 to -90 dBm per element (Low Power Mode) [TCAS and Transponder] +1 to -69 dBm per element (High Power Mode) [TCAS] +1 to -98 dBm [UAT]
Resolution:	1 dB
Accuracy:	+/- 1 dB, typically < +/- 0.5 dB
Chamber Mode:	+10 to -60 dBm (TTG-7000 with TTG-7000C)
Port:	Top (4 Elements), Bottom (4 Elements), Any Individual Element
Calibration:	Calibrated at 1090, 1030, and 978 (UAT option unit) MHz Calibration performed on top/bottom (All ports active)
Pulse Modulation:	
Accuracy:	+/- 0.05 uS
On/Off Ratio:	>80dB
Rise/Fall Time:	Normal (<50 nS)/Slow (600 nS)
Bearing Simulation:	

Range:	0 to 359°
Resolution:	1°
Accuracy:	Typical <+/- 1°, max +/- 3° (4 Port Simulation) +/- 4° (Vector Voltmeter Port to Port)
Range Simulation:	
Range:	0 to 150 NMI
Resolution:	12.5 Feet
Accuracy:	+/- 200 Feet
Velocity Simulation:	
Range:	+/- 2000 Kt/Hr
Resolution:	1 Kt/Hr
Accuracy:	+/- 1 Kt/Hr
Vertical Speed Simulation:	
Range:	+/- 32608 Ft/Min
Resolution:	64 Ft/Min
Accuracy:	+/- 64 Ft/Min
Altitude Simulation:	
Range:	-1000 to 126700 Feet
Mode:	Gilham and 25 Feet
Resolution:	25/100 Feet up to 50175 Feet 100 Feet above 50175 Feet
<u>Receiver Specifications:</u>	
VSWR:	<1.4
Maximum Input Power:	+60 dBm
Antenna Simulation:	Internal with Antenna Resistors for ACSS, Collins, and Honeywell
Receivers:	1030 MHz with BPSK Demodulation 1090 MHz 978 MHz [UAT Option]
Dynamic Range:	40 dB minimum
Dual Receiver:	Top/Bottom
Power Measurement:	
Range:	+17 to +60 dBm
Resolution:	0.1 dB
Accuracy:	0.5 dB

Relative Phase Measurement:

Range: 0 to 359 degrees
Resolution: 1 degree
Accuracy: +/- 4 degrees

Frequency**Measurement:**

Resolution: 0.2 KHz
Accuracy: 1 KHz (Using Special Test Mode); +/- 10 KHz

Pulse Characteristic Measurement:

Resolution: 10 nS

Software Interfaces:

Ethernet
GPIB
USB 2.0
VNC Viewer

Interfaces:

Suppression Bus (Front/Rear)
ATE Lines (Front/Rear)
429 Tx/Rx (Front/Rear)
Two Scope Outputs (Front/Rear)
LAN (Front/Rear)
USB Type B Control (Front)
Two USB Type A (Front) for Peripherals (Flash Disk, HID ...)
Six External I/O Ports (Rear) [Application Specific]
Top/Bottom RF Coupled Outputs

Calibration Cycle:

Typically 1 year

2. Hardware




Figure 2.1 – TTG-7000 TCAS\Transponder RF Generator with Chamber RF Amplifier (TTG-7000C)

TTG-7000 Front Interfaces

- 1 Color LCD Touch Screen Display
- 2 Ethernet RJ-45 jack for remote control of test set via TCP/IP. Another RJ-45 jack is provided in the rear.
- 3 USB Type B jack for remote control of test set.
- 4 Two (2) USB Type A jacks for interface to external USB devices (Keyboards, mouse, flash drives..)
- 5 Power Switch and Indicator
- 6 Eight (8) Antenna Ports. T1/T2/T3/T4/B1/B2/B3/B4
- 7 ATE Line input. This connection is also available in the rear. It contains discrete inputs, discrete outputs, and 429 Tx/Rx.
- 8 Suppression Input/Output
- 9 Scope Channel 1
- 10 Scope Channel 2




Figure 2.2 – TTG-7000 TCAS\Transponder RF Generator (Rear)

TTG-7000 Front Interfaces

- 1 Ethernet RJ-45 jack for remote control of test set via TCP/IP. Another RJ-45 jack is provided in the front.
- 2 Spectrum Analyzer Output. Coupled output from the Top Receiver. SMA Jack
- 3 Spectrum Analyzer Output. Coupled output from the Bottom Receiver. SMA Jack
- 4 Aux Control Port. D-Sub 25 Pin Female. [TTG-7000C Interface Port]
- 5 External I/O Ports 1-6. BNC Jack [Application Specific]
- 6 Scope Channel 1
- 7 Scope Channel 2
- 8 Suppression Input/Output
- 9 ATE Line Port. D-Sub 37 Pin Male.
- 10 GPIB Bus Port
- 11 Fan
- 12 Power Supply. 115/230 VAC, 50/60 Hz




Figure 2.3 – TTG-7000C RF Amplifier (Chamber) Front

- 1 T1 Port – Connect to TTG-7000 T1 Port (Receiver Port)
- 2 B1 Port – Connect to TTG-7000 B1 Port (Ground Station and UF Interrogations)
- 3 B2 Port – Connect to TTG-7000 B2 Port (Generator 1 Port)
- 4 B3 Port – Connect to TTG-7000 B3 Port (Generator 2 Port)
- 5 B4 Port – Connect to TTG-7000 B4 Port (Generator 3 Port)
- 6 Power Indicator




Figure 2.4 – TTG-7000C RF Amplifier (Chamber) Rear

- 1 Antenna 1 - 0° Port
- 2 Antenna 2 - 45° Port
- 3 Antenna 3 - 90° Port
- 4 Antenna 4 - 135° Port
- 5 Antenna 5 - 180° Port
- 6 Antenna 6 - 225° Port
- 7 Antenna 7 - 270° Port
- 8 Antenna 8 - 315° Port
- 9 GS – Ground Station and UF Interrogations Port
- 10 Rx – Receiver Port
- 11 Aux Control Port. D-Sub 25 Pin Female Jack. Connect to TTG-7000 Aux Control Port on rear. Connect cable with power off on TTG-7000.




Figure 2.5 – TTG-7000 429 Input Adapter [Optional]

3. TouchScreen Application

3.1. Main Menu

Figure 3.1.1 illustrates the TTG-7000 Main Menu. The Main Menu shows status of test set configuration and software versions.




Diagram Item	Softkey	Function
1	No	Shows status of the test set configuration and software version. Software and firmware versions can be refreshed by pressing ALT + R.
2	No	The Unit Part Number Illustrated with the base number (90-7000) and the dash number provides the hardware version and the software version of the test set. The first two characters of the dash number represent the hardware version (04 in example in the Figure 3.1.1). The last







Diagram Item	Softkey	Function
		two characters represent the software version (B4 in the example in Figure 3.1.1).
3	No	Server (Kernel) Software version.
4	No	User Interface (TouchScreen) version.
5	No	Receiver DSP embedded software version.
6	No	I/O Controller Receiver FPGA firmware version.
7	No	Transmitter DSP embedded software version.
8	No	I/O Controller Transmitter FPGA firmware version.
9	No	FPGA firmware version of all subassemblies present, including auxiliary equipment (i.e. Chamber Test Set if connected).
10	No	Status Menu (present on all TouchScreen menus).
11	No	<p>Ethernet command reception status.</p> <p>Ethernet commands can be received either from the front or rear RJ-45 Ethernet ports.</p>  <p>Front/Rear LAN port is connected.</p>  <p>No LAN port is connected.</p>
12	No	<p>USB control port status.</p> <p>Provides status whether or not the front USB Type B port for control is connected.</p>  <p>USB Connected</p>  <p>USB Disconnected</p>
13	No	<p>GPIB command reception status.</p>  <p>GPIB Active</p>  <p>GPIB Inactive</p>
14	No	<p>Local/Remote Indication. Setting of Local/Remote mode only by remote command.</p> <p>Local Remote</p> <p>Local Mode - all controls in the touchscreen are enabled.</p>





Diagram Item	Softkey	Function
		<p>Remote <small>Local</small></p> <p>Remote Mode - all controls in the touchscreen are disabled.</p>
15	No	<p>Up/Down Softkey.</p> <p>The up/down arrows if not grayed illustrates that there exist more softkeys either up or down.</p>
16	No	<p>Menu Softkey Section.</p> <p>This section is contained in all menus. If a softkey button contains an arrow to the right, that softkey will open another menu.</p>
17	No	<p>Return to Previous Menu Softkey.</p> <p>This softkey if not grayed allows the user to return to the previous menu.</p>
18	No	<p>Touchscreen/Normal Controls.</p> <p></p> <p>Touchscreen Mode – When the user presses a control a numeric keypad (Figure 3.1.5), keyboard (Figure 3.1.6), or listbox (Figure 3.1.4) will appear on the screen for selection or entry of the parameter.</p> <p></p> <p>Normal Mode – User can modify the controls on the screen using touchscreen or external mouse/keyboard.</p>
19	No	<p>Error/Configuration warning.</p> <p></p> <p>This warning triangle is only illustrated if the configuration does not match with the subassemblies present in the system or a DSP or FPGA firmware version is incorrect.</p> <p></p> <p>If Exclamation warning is illustrate then an error has occurred. Place the mouse cursor over the exclamation warning to get a description of the error. Or double click to go to the error menu to see list of errors.</p>
20	No	<p>Safely Remove Hardware Icon.</p> <p>Press this icon to open safely remove hardware dialog. (In the example in Figure 3.1.3)</p>
21	No	Explorer Icon.

Diagram Item	Softkey	Function
		Press this icon to open windows explorer. (In the example in Figure 3.1.2)
22	No	On Screen Keyboard Icon. Press this icon to open the on screen keyboard for data entry.
	Yes	TCAS Menu Allows user to enter TCAS Menu.
	Yes	Transponder Menu Allows user to enter Transponder Menu.
	Yes	System Menu Allows user to enter System Menu.
	Yes	UAT Menu Allows user to enter UAT Menu. [Optional]
	Yes	OEM Select. Allows selection of TCAS OEM. Honeywell Directional Honeywell OMNI Collins Phase Directional Collins Phase OMNI Collins Magnitude Directional Collins Magnitude OMNI ACSS Directional ACSS OMNI Garmin Avidyne TAS Avidyne ADSB
	Yes	Support Menu. If connection to the Internet is available, menu illustrates ATG TTG-7000 Support Page. Allows downloading of latest TTG-7000 software for update.
	Yes	User's Manual. Illustrates a PDF copy of this manual on screen.




Figure 3.1.2 – Windows Explorer Icon.




Figure 3.1.3 – Safely Remove Hardware Icon.




Figure 3.1.4 – TouchScreen Listbox Control




Figure 3.1.5 – Touchscreen Numeric Control



Figure 3.1.6 – Touchscreen Keyboard Control

3.1.1. System Menu

Figure 3.1.1.1 illustrates the TTG-7000 System Menu. The System Menu allows the user to set different system parameters (i.e. GPIB address, Product Key, Scope Port Outputs ...).




Figure 3.1.1.1 – TTG-7000 System Menu

Diagram Item	Softkey	Function
1	No	Unit Serial Number
2	No	Unit Part Number
3	No	Unit Hardware Version
4	No	Unit Software Version
5	No	Product Key. The product key enables/disables options in the TTG-7000 test set. ATG will provide the product key.
6	Yes	Current GPIB Address. GPIB address can be modified using this combo box control or GPIB softkey. GPIB address range 1 -31. Once the GPIB address is set, the TTG-7000 GPIB address on all future power up cycles will be the same.

Diagram Item	Softkey	Function
		If a software update is performed then you may have to reset the GPIB address.
7	Yes	Scope Port 1. User can select from multiple test set signal lines (i.e. Log Video, DPSK Demodulation, Transmitter Modulation ...). The user can use the combo box control or softkey to select the signal. The user selection is saved and the same selection will be used on future power up cycles.
8	Yes	Scope Port 2. User can select from multiple test set signal lines (i.e. Log Video, DPSK Demodulation, Transmitter Modulation...). The user can use the combo box control or softkey to select the signal. The user selection is saved and the same selection will be used on future power up cycles.
	Yes	Network Connections Shows Hostname and IP address of TTG-7000. Allows setting the Ethernet adapters of the TTG-7000
	Yes	429 Configuration Menu Allows configuration of the 429 inputs of the 429 adapter for the TTG-7000.
	Yes	Update Key Validates the product key entered in menu control item 4.
	Yes	Software Update Menu Allows programming of DSP software and FPGA firmware.
	Yes	Calibration History Illustrates the last calibration date and result.
	Yes	Error Log Shows any command failures via GPIB, Ethernet, or USB.
	Yes	Touch Align Executes Touch Screen Alignment Program
	Yes	Display Settings Opens Windows Display Settings

3.1.1.1. Software Update Menu

Figure 3.1.1.1.1 illustrates the TTG-7000 Software Update Menu. The Software Update Menu allows the user to update the DSP software or the FPGA firmware.




Figure 3.1.1.1.1 – TTG-7000 Software Update Menu

Diagram Item	Softkey	Function
1	No	Programming Enable Enables/disables the programming of a specific DSP or FPGA device.
	Yes	Select Opens a file dialog to select the programming configuration file.
	Yes	Execute Programs all the FPGAs and DSPs that have the programming enable.
	Yes	Cancel Cancels the programming sequence.
	Yes	Refresh Versions

Diagram Item	Softkey	Function
		Refreshes the software and firmware versions.

Note: If you place the cursor in the “**Selected Programming Script File**” textbox on the top of the screen and press **Alt+S**, the Touchscreen software will read the last valid configuration file and displays all the valid FPGA and DSP versions.

Software Update Process:

1. Kernel and Touchscreen software are updated.
2. Kernel and Touchscreen software are executed.
3. Touchscreen software automatically starts in the Software Update Menu and programs all necessary DSP software and FPGA firmware for the updated software.
4. If step 4 is not accomplished because of an update failure. Follow the instructions on the note above to program the DSPs and FPGAs.

1. Network Connections Menu

Figure 3.1.1.2.1 illustrates the TTG-7000 Network Connections Menu. The Network Connections Menu illustrates the current network settings and allows changing the network settings. There should be three connections: 1) Front LAN; 2) Rear LAN; 3) DSP Connection (Names could be different). The screen will illustrate the current settings whether the IP is static or dynamic and if connected what is the current IP address. The internal connection is at IP Address 192.168.0.1 (Factory Setting). ATG recommends that if you are not required to use this address for the external connections, not to change the internal IP address. All Ethernet communications to the TTG-7000 are on port 2001.




Figure 3.1.1.2.1 – TTG-7000 Network Connections Menu

Diagram Item	Softkey	Function
1	No	Shows the current settings of all the Ethernet adapters.
	Yes	Refresh Refreshes the menu with the network settings of all the Ethernet adapters.
	Yes	Change Settings Illustrates the network connection change settings menu for the selected Ethernet connection.

For example, user wants to change the IP of the Rear LAN from dynamic to static. Select the Rear LAN line on the grid of the current menu and press the “**Change Settings**” Softkey.

Figure 3.1.1.2.2 illustrates the TTG-7000 Network Connections Change Settings Menu. To change the IP address to a static IP select the “**Use the following IP Address**” group box. Enter the IP address, Subnet Mask, and Gateway Address. Press the “**Set**” softkey and the IP address will be changed to a static IP. To change to a dynamic IP, select the “**Obtain an IP Address automatically**” group box and press the “**Set**” softkey.




Figure 3.1.1.2.2 – TTG-7000 Network Connections Change Settings Menu

Diagram Item	Softkey	Function
1	No	Selection of IP address Either automatically (DHCP) or fixed.
2	No	IP Configuration If fixed IP is selected, then IP Address, Subnet Mask, and Gateway controls are enabled to allow the user to enter the specific information. If automatic IP is selected, then the settings provided by the DHCP server are illustrated.
	Yes	Set Pressing this softkey allows the acceptance of the information entered by the user.

The internal DSP IP address can also be changed from the factory default of 192.168.0.1, but ATG recommends not changing it, only if the IP address is needed by the external LAN connections. On the Network Connections Menu select the DSP connection row on the grid and press the **“Change Settings”** softkey. A screen similar to Figure 3.1.1.2.3 should appear.




Figure 3.1.1.2.3 – TTD-7000 Internal Network Change Settings Menu

Enter the IP address desired for the internal DSP connection. The TTD-7000 will set the gateway address to the same IP Address, and will internally set the DSP IP address and will communicate the address to the DSP module when the operator presses the **“Set”** Softkey. The application software will communicate the new address to the DSP, reset the connection, and reboot the DSP. This process will take a few minutes. At the end of the process the application software will reestablish communications with the DSP using the new IP Address. On every future reboots the current IP address will be used. If the operator wants to return to the factory setup, enter the same screen and press **“Factory Setup”**. The application software will start the previously mention process with the IP address set to 192.168.0.1.

3.1.1.3. 429 Configuration Menu

Figure 3.1.1.3.1 illustrates the TTG-7000 429 Configuration Menu that allows the user to select the 429 input channel for Altitude, Latitude, Longitude, Heading, and UTC Time. For Latitude, Longitude, and Heading the menu allows selection of 429 label.




Figure 3.1.1.3.1 – TTG-7000 429 Configuration Menu

Diagram Item	Softkey	Function
1	Yes	Altitude 429 Position. Allows the user to select the input port of the 429 adapter (A1B1, A2B2, or A3B3) for the altitude data.

Diagram Item	Softkey	Function
		Selection is maintained on future power up cycles. Label 203 is used.
2	Yes	Latitude 429 Position and label configuration. Allows the user to select the input port of the 429 adapter (A1B1, A2B2, or A3B3) for the latitude data and also the 429 label (110/120, 254, or 310) to use. Selections are maintained on future power up cycles.
3	Yes	Longitude 429 Position and label configuration. Allows the user to select the input port of the 429 adapter (A1B1, A2B2, or A3B3) for the longitude data and also the 429 label (111/121, 255, or 311) to use. Selections are maintained on future power up cycles.
4	Yes	Heading 429 Position and label configuration. Allows the user to select the input port of the 429 adapter (A1B1, A2B2, or A3B3) for the heading data and also the 429 label (320, 314, or 313) to use. Selections are maintained on future power up cycles.
5	Yes	UTC Time Position configuration. Allows the user to select the input port of the 429 adapter (A1B1, A2B2, or A3B3) for the UTC time data. Selections are maintained on future power up cycles. Label 150 is used.

3.1.2. TCAS Main Menu

Figure 3.1.2.1 illustrates the TTG-7000 TCAS Main Menu. The TCAS Main Menu allows the user to select from multiple submenus for testing of a TCAS system.




Figure 3.1.2.1 – TTG-7000 TCAS Main Menu

Diagram Item	Softkey	Function
1	No	This area illustrates TCAS test options enabled for the current product key.
	Yes	Settings Allows the user to set generator frequency and troubleshoot TTG-7000.
	Yes	Measurements Allows the user to view the transmissions of the unit under test and to perform pulse characteristic, frequency, and phase measurements.
	Yes	Own Aircraft Allows the user to change the own aircraft information if set to manual. If not set to manual entry, the user the

Diagram Item	Softkey	Function
		own aircraft information from the selected source is displayed in this menu.
	Yes	Receiver Allows the user to select messages to capture and log from the unit under test or the TTG-7000. Allows viewing of engineering units of received messages.
	Yes	Transmitter Allows the user to perform either DO-260 tests or Block Transmissions.
	Yes	ATE Lines Menu Allows the user to view the ATE Line transmissions from the unit under test.
	Yes	Scenario Allows the user to design and execute a scenario test.
	Yes	Chamber Mode Allows the user to enter the path loss for the chamber setup with the TTG-7000C.

3.1.2.1. TCAS Settings Menu

Figure 3.1.2.1.1 illustrates the TTG-7000 TCAS Settings Menu. The TCAS Settings Menu allows the user to configure the Transmitter, Receiver, and Antenna Simulator modules within the test set. This menu is mainly used for testing and troubleshooting of the TTG-7000. For TCAS unit testing, this menu should only be used to set the individual RF generator frequencies.




Figure 3.1.2.1.1 – TTG-7000 TCAS Settings Menu

Diagram Item	Softkey	Function
1	Yes	OEM Select Allows the user to select the TCAS system OEM. The antenna resistors are set according to OEM selection. Also the calibration tables to emulate the bearing of intruders are loaded according to the OEM selection. OEM selections are Honeywell Directional, Honeywell Omni, Collins Phase Directional, Collins Phase Omni,

Diagram Item	Softkey	Function
		ACSS Directional, ACSS Omni, Collins Magnitude Directional, Collins Magnitude Omni, Garmin or Avidyne.
2	Yes	Power Mode Allows the user to select between high or low power modes. Low power allows setting the output power from -20 to -90 dBm. High power allows setting the power from 1 to -69 dBm.
3	Yes	Receiver Path Allows the user to select which port to connect the Top/Bottom Receiver. Selections available are Rx T1/B1, Rx T2/B2, Rx T3/B3, Rx T4/B4, Chamber, or Combiner. Note : On Collins Magnitude or ACSS this setting is automatically switched to Combiner.
4	Yes	Phase Noise Amplitude. Future use.
5	Yes	Suppression Out On/Off. Future use.
6	Yes	Tx Frequency Allows the setting of the Transmitter frequency. Individual setting for each transmitter. Range from 962 to 1213 MHz in 0.1 MHz steps. To use softkey, Press Signal Generator softkey then the appropriate Generator.
7	Yes	Tx Power Allows the setting of the Transmitter power from -20 to -90 dBm in 1 dB steps in low power mode or from 1 to -69 dBm in 1 dB steps in high power mode.
8	Yes	Tx Path Allows setting the Tx path to Top All Ports/Bottom All Ports/Single Port. Selections are T1, T2, T3, T4, Top (All), B1, B2, B3, B4, and Bottom (All).
9	Yes	Phase (Bearing) for the specific Transmitter. Range 0 to 359 degrees in 1-degree steps.
10	Yes	Modulation CW/Pulse
11	Yes	Signal Generator On/Off
12	Yes	Pulse Risetime/Falltime. Selections are 50/50, 100/200, 230/230, 600/600, and Nominal. Rise and fall times can be changed on generator A, C, and E.
13	Yes	Pulsewidth Allows the user to adjust the pulsewidth of all the transmissions by +/- 100 nanoseconds in 25 nanosecond steps.
	Yes	Factory Setup Sets all hardware to default setting according to hardware configuration.

Note: Selection of OEM changes the Antenna Simulation module, the antenna resistors, and loads the calibration tables for bearing for the selected OEM.

3.1.2.2. Own Aircraft Menu

Figure 3.1.2.2.1 illustrates the TTG-7000 Own Aircraft Menu. The TCAS Own Aircraft Menu allows the user to change the latitude, longitude, altitude, heading, and Mode S address of the own aircraft (TCAS under test).




Figure 3.1.2.2.1 – TTG-7000 TCAS Own Aircraft Menu

Diagram Item	Softkey	Function
1	Yes	Mode S Address (24 bits). Hexadecimal
2	Yes	Latitude Allows the user to enter the latitude of the own aircraft. Range from -90 to 90 degrees.
3	Yes	Longitude Allows the user to enter the longitude of the own aircraft. Range from -180 to 180 degrees.
4	Yes	Altitude Allows the user to enter the altitude of the own aircraft in feet. Range from -1000 to 64535 feet.

Diagram Item	Softkey	Function
5	Yes	Heading Allows the user to enter the heading of the own aircraft in degrees. Range from -180 to 180 degrees.
	Yes	Broadcasting Allows entry of UDP information for broadcasting Own Aircraft information via UDP.

Note: When an external source (Ethernet or 429) is used the own aircraft information is updated every 5 seconds when a Scenario is not running. The data is updated every second if the scenario is running.

Figure 3.1.2.2.2 illustrates the TTG-7000 Own Aircraft Menu Broadcasting Setting Menu. This menu allows the user to setup the UDP parameters for broadcasting the own aircraft data.




Figure 3.1.2.2.2 – TTG-7000 TCAS Own Aircraft Broadcasting Setting Menu

Diagram Item	Softkey	Function
1	Yes	UDP Port Number
2	Yes	IP Broadcast Address. Selection between any or broadcast. If broadcast is selected then IP address entry is allowed.
3	Yes	Start/Stop Broadcasting

3.1.2.3. TCAS Receiver Menu

Figure 3.1.2.3.1 illustrates the TTG-7000 TCAS Receiver Menu. The TCAS Receiver Menu allows the user to view the transmissions from the TCAS system and the transmissions from the TTG-7000 test set.




Figure 3.1.2.3.1 – TTG-7000 TCAS Receiver Menu

Diagram Item	Softkey	Function
1	No	Top section of the Receiver Menu Illustrates the status of reception from either the TCAS system under test or from the test set. There is a LED associated for the ATCRBS Reply, DF Reply, ATCRBS Interrogation, and UF Interrogation for the TCAS System (Rx Group) and the test set (Tx Group). For UAT option, LEDs are shown in the Rx and Tx group.
2	No	Reception section

Diagram Item	Softkey	Function
		Shows the last 8 receptions. Lines in blue represent receptions from the TCAS system. Lines in green represent receptions from the test set.
	Yes	Capture→ UUT DF Enable/disable capture of Transponder DF messages. TTG DF Enable/disable capture of test set DF messages. UUT UF Enable/disable capture of TCAS UF messages. TTG UF Enable/disable capture of test set UF messages. UUT ATCRBS Reply Enable/disable capture of Transponder ATCRBS replies. TTG ATCRBS Reply Enable/disable capture of test set ATCRBS replies. UUT ATCRBS Intr Enable/disable capture of TCAS ATCRBS interrogations. TTG ATCRBS Intr Enable/disable capture of test set ATCRBS interrogations. UUT UAT Enable/disable capture of UAT messages (Optional). TTG UAT Enable/disable capture of UAT messages from test set (Optional).
	Yes	Display→ Display Allows turning on/off displaying new receptions. UTC Time Enable/Disable UTC time stamp. UTC Time Source PC Time, 429, or GPS. Mode Update Display data received by updating a message style with the latest reception. Continuous Display all data received in a continuous order by time. Time Relative Display time relative to previous message. Absolute

Diagram Item	Softkey	Function
		<p>Display the time received.</p> <p>Clear Clears all messages in the receiver menu.</p> <p>Quantity to Show Allows entering how many messages to show. (Maximum 1000 messages)</p> <p>Refresh Refreshes the receiver menu with the selected quantity of messages.</p> <p>Frame Details Illustrates the detail breakdown of a selected reception. See Figure 3.1.2.3.2. The detail breakdown of message can also be displayed, by turning off the Display softkey and double clicking on the desired message.</p>
	Yes	<p>Data Logging→</p> <p>Record/Stop Allows start and stopping data logging receive messages.</p> <p>Export Allows exporting received messages to file.</p> <p>Clear Clears all recorded messages.</p>
	Yes	Filtered Masked Menu
	Yes	Highlight Masked Menu

When performing an export the TTG-7000 generates a SDF (Compact Database File) and exports the file to the selected file location. The operator can download from ATG's website a Reporting Tool that will display the contents of the SDF file and will allow the user to generate multiple CSV files from the exported data. Also all the DF17 position, velocity, and identification messages are decoded in the Reporting Tool.

Name	Value	Units	LSB	Description	Low	High
UF	0	N/A	0		0	0
Spare	0	N/A	0		0	0
Reply Length	0	N/A	0		0	1
Spare	0	N/A	0		0	0
Acquisition Special	0	N/A	0		0	1
BD	0	N/A	0		0	30
Spare	0	N/A	0		0	0

Rx Frame Details Menu

Local Remote

▲

UF

0

▲ ▼

Spare

0

▲ ▼

Reply Length

0

▲ ▼

▼

↶ ↷

Figure 3.1.2.3.2 – TTG-7000 TCAS Receiver Frame Detail Menu

3.1.2.3.1. TCAS Receiver Filtered Masked Menu

Figure 3.1.2.3.1.1 illustrates the TTG-7000 TCAS Receiver Filtered Masked Menu. The TCAS Receiver Filtered Masked Menu allows the user to select what messages to filter and display in the Receiver menu.




Figure 3.1.2.3.1.1 – TTG-7000 TCAS Receiver Filtered Masked Menu

Diagram Item	Softkey	Function
	Yes	Predefined Mask Allows selection of predefined masks.
	Yes	Customize Mask Allows user to customize mask and pattern.




Figure 3.1.2.3.1.2 - Predefined Mask Filter

Diagram Item	Softkey	Function
1	No	Groups of UF and DF messages.
2	No	Sub messages of the selected group.
3	No	Messages selected to perform filter.
	Yes	Select All Selects all messages to be displayed. No filter is applied.
	Yes	Unselect All Unselects all messages, therefore no messages are displayed.

Note: Individual messages are selected using the es in menu control section 2 of Figure 3.1.2.3.1.2.

3.1.2.3.2. TCAS Receiver Highlight Masked Menu

Figure 3.1.2.3.2.1 illustrates the TTG-7000 TCAS Receiver Highlight Masked Menu. The TCAS Receiver Highlight Masked Menu allows the user to select what messages to highlight during display of messages in the Receiver menu.




Figure 3.1.2.3.2.1 – TTG-7000 TCAS Receiver Highlight Masked Menu

Diagram Item	Softkey	Function
1	No	Groups of UF and DF messages.
2	No	Sub messages of the selected group.
3	No	Messages selected to perform highlight.
	Yes	Select All Selects all messages to be highlighted.
	Yes	Unselect All Unselects all messages, therefore no messages are highlighted.

Note: To enable highlighting of individual messages check the appropriate es in menu control section 2 of Figure 3.1.2.3.2.1.

3.1.2.4. TCAS Transmitter Menu

Figure 3.1.2.4.1 illustrates the TTG-7000 TCAS Transmitter Menu. The TCAS Transmitter Menu allows the user to implement a block of transmissions or RTCA DO-260 tests.




Figure 3.1.2.4.1 – TTG-7000 TCAS Transmitter Menu

Diagram Item	Softkey	Function
	Yes	RTCA/DO-260 Tests Displays a menu that allows the user to set the TTG-7000 generators to perform RTCA DO-260 tests.
	Yes	Block Transmissions Displays a menu that allows the user to set a group of messages (UF, DF, ATCRBS Interrogation, and ATCRBS Replies) to transmit at a specific time and block period.

3.1.2.4.1. RTCA/DO-260 Tests

Figure 3.1.2.4.1.1 illustrates the TTG-7000 RTCA/DO-260 Tests Menu. The TTG-7000 RTCA/DO-260 Tests Menu allows the user to define tests that set the TTG-7000 transmitters for RTCA DO-260 receiver testing.




Figure 3.1.2.4.1.1 – RTCA/DO-260 Tests Menu

Diagram Item	Softkey	Function
1	No	This section illustrates special test selected.
2	No	This section illustrates timing settings.
3	No	This section illustrates generator settings.
4	Yes	Power Mode Low power range -20 to -90 dBm. High power range +1 to -69 dBm
	Yes	Load Allows loading a stored DO-260 test. Most RTCA DO-260 tests have been predefined and can be loaded using this softkey.

Diagram Item	Softkey	Function
	Yes	Save Allows saving the current DO-260 test.
	Yes	Reset Resets the test settings to the default values.
	Yes	Special Test Definition Opens a new menu that allows setting one of the special tests (Normal, Altered Preamble, Bit Failures, Overlapping Pulse, Preamble Validation, or Confidence Test). Figure 3.1.2.4.1.2 shows the normal test setting. Figure 3.1.2.4.1.3 shows the altered preamble setting. Figure 3.1.2.4.1.5 shows the bit failures setting. Figure 3.1.2.4.1.6 shows the overlapping pulse setting. Figure 3.1.2.4.1.7 shows the preamble validation setting. Figure 3.1.2.4.1.8 shows the confidence test setting.
	Yes	Timing Definition Opens a new menu that allows setting the timing definitions.
	Yes	Generator Definition Opens a new menu that allows setting the generator definitions.
	Yes	Test Start/Stop Allows the user to start or stop the defined DO-260 test.

Figure 3.1.2.4.1.2 illustrates the RTCA/DO-260 Special Test Normal Definition Menu. The normal selection does not allow altering any parameters.




Figure 3.1.2.4.1.2 – RTCA/DO-260 Special Test Definition Normal Menu

Diagram Item	Softkey	Function
1	Yes	Special Test Allows setting type of special test (Normal, Altered Preamble, Bit Failures, Overlapping Pulse, Preamble Validation, or Confidence Test).

Figure 3.1.2.4.1.3 illustrates the RTCA/DO-260 Special Test Altered Preamble Definition Menu. This menu allows the operator to change the preamble pulses of the Mode S message. The width, position, power and visibility of each of the preamble pulses can be changed. Transmissions are sent simultaneously on the top and bottom antennas.




Figure 3.1.2.4.1.3 – RTCA/DO-260 Special Test Definition Altered Preamble Menu

Diagram Item	Softkey	Function
1	Yes	Special Test Allows setting type of special test (Normal, Altered Preamble, Bit Failures, Overlapping Pulse, Preamble Validation, or Confidence Test).
2	Yes	Preamble section Allows alteration of Mode S preamble (Width, Position, Reference Power, and Enable). Displays the softkeys to change the Mode S preamble parameters. Reset Pulse 1 → Width Range 0 to 5000 ns Position Range -5000 to 675 ns Power Gen A or Gen B Enable On/Off Pulse 2 → Width Range 0 to 4500 ns

Diagram Item	Softkey	Function
		Position Range 675 to 1425 ns Power Gen A or Gen B Enable On/Off Pulse 3 → Width Range 0 to 4500 ns Position Range 3075 to 3925 ns Power Gen A or Gen B Enable On/Off Pulse 4 → Width Range 0 to 4500 ns Position Range 4075 to 4925 ns Power Gen A or Gen B Enable On/Off

Figure 3.1.2.4.1.4 illustrates the TTG-7000 RTCA/DO-260 Tests Menu after altered preamble is selected for the special test. The screen illustrates the timing parameters, the generators that are being used, and in the case of altered preamble the preamble settings on the bottom of the screen.

The screenshot displays the RTCA/DO-260 Tests Menu with the 'Altered Preamble' special test selected. The interface includes a top section for Special Test and Power Mode, a Timing section for Trigger Source, Mode, and Period, and a table for Generator settings. A Preamble section at the bottom allows configuration for four pulses (P1-P4).

Special Test: Altered Preamble **Power Mode:** Low Power

Timing

Trigger Source: Gen A Period (msecs): 10

Trigger Mode: Delay + No. Transmissions: No Limit

Random Start (nsecs): 0 Random Width (nsecs): 120000

Generator	Enable	Frequency	Power	Phase	Path	Delay	Message Type
Gen A	Yes	1090.0	-20	0	Top(All)	0	Mode S
Gen B	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Gen C	Yes	1090.0	-20	0	Top(All)	0	Altered Preamble
Gen D	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Gen E	N/A	N/A	N/A	N/A	N/A	N/A	N/A
Gen F	N/A	N/A	N/A	N/A	N/A	N/A	N/A

Preamble

Pulse	Width (nsecs)	Position (nsecs)	Reference Power	Enable
P1	500	0	Gen A	Yes
P2	500	1000	Gen A	Yes
P3	500	3500	Gen A	Yes
P4	500	4500	Gen A	Yes

RTCA/DO-260 Tests Menu

Local Remote

Load

Save

Reset

Special Test Definition

Timing Definition

Generator Definition

Test

Start

Stop

Figure 3.1.2.4.1.4 – RTCA/DO-260 Tests Menu (Altered Preamble)

Note: In the Altered Preamble mode the message defined is transmitted on the top and bottom antenna simultaneously.

Figure 3.1.2.4.1.5 illustrates the RTCA/DO-260 Special Test Bit Failures Definition Menu. This menu allows the operator to specify the start chip and the ending chip for energy on both sides of the Manchester code, and also allows selections of bad bits (inverted after PI Calculation).




Figure 3.1.2.4.1.5 – RTCA/DO-260 Special Test Definition Bit Failures Menu

Diagram Item	Softkey	Function
1	Yes	Special Test Allows setting type of special test (Normal, Altered Preamble, Bit Failures, Overlapping Pulse, Preamble Validation, or Confidence Test).
2	Yes	Energy in Chips section Allows setting the start and ending chip with energy on both parts of the bit.
3	Yes	Bad Chips Selects the bits that will be inverted after the calculation of the PI Field.

Note: In the Special Test Bit Failures mode the message defined is transmitted on the top and bottom antenna simultaneously.

Figure 3.1.2.4.1.6 illustrates the RTCA/DO-260 Special Test Overlapping Pulse Definition Menu. This menu allows the operator to specify the delay from P1 and pulse width of the overlapping pulse.




Figure 3.1.2.4.1.6 – RTCA/DO-260 Special Test Definition Overlapping Pulse Menu

Diagram Item	Softkey	Function
1	Yes	Special Test Allows setting type of special test (Normal, Altered Preamble, Bit Failures, Overlapping Pulse, Preamble Validation, or Confidence Test).
2	Yes	Pulse section Allows setting the starting position and width of the overlapping pulse.

Note: In the Overlapping Pulse mode the message defined is transmitted on the top and bottom antenna simultaneously.

Figure 3.1.2.4.1.7 illustrates the RTCA/DO-260 Special Test Preamble Validation Definition Menu. This menu allows the operator to specify the chips that have energy on both halves of the chip and chips that have no energy in both halves. This menu also allows defining a delta amplitude for each half of the chip.




Figure 3.1.2.4.1.7 – RTCA/DO-260 Special Test Preamble Validation Menu

Diagram Item	Softkey	Function
1	Yes	Special Test Allows setting type of special test (Normal, Altered Preamble, Bit Failures, Overlapping Pulse, Preamble Validation, or Confidence Test).
2	Yes	Energy Chips section Allows setting the chips that have energy on both halves of the chips and chips that have no energy.

Note: If the “Include Delta Amplitude (No Energy in chips)” is selected than the no energy signal will be at the delta amplitude level.

Note: In the Preamble Validation mode the message defined is transmitted on the top and bottom antenna simultaneously.

Figure 3.1.2.4.1.8 illustrates the RTCA/DO-260 Special Test Confidence Test Definition Menu. This menu allows the operator to specify upto five (5) chips that have energy on both halves of the chip and five (5) chips that are bad chips (data bit is reverse). For bad chips the PI field is calculate using the correct data and then the chip value is reversed.




Figure 3.1.2.4.1.8 – RTCA/DO-260 Special Test Confidence Test Menu

Diagram Item	Softkey	Function
1	Yes	Special Test Allows setting type of special test (Normal, Altered Preamble, Bit Failures, Overlapping Pulse, Preamble Validation, or Confidence Test).
2	Yes	Confidence test section Allows setting five chips that have energy on both halves of the chips and five bad chips that the data is reversed after calculating PI field.

Note: In the Confidence Test mode the message defined is transmitted on the top and bottom antenna simultaneously.

Figure 3.1.2.4.1.9 illustrates the RTCA/DO-260 Timing Definition Menu. This menu allows the operator to specify the timing parameters for the test.




Figure 3.1.2.4.1.9 – RTCA/DO-260 Timing Definition Menu

Diagram Item	Softkey	Function
1	Yes	Trigger Source Allows selection of generator to trigger from.
2	Yes	Trigger Mode Allows selection of mode (Delay +, Delay -, Random, or walk). If random is selected then two more numeric boxes are added to the screen to select minimal starting time and the width of the random starting time. If delay is selected then the delay defined in the generator setting is used for + or – delay. Walk allows setting a signal at a positive or negative delay and

Diagram Item	Softkey	Function
		moving the signal by 25 nanosecond delay every transmission.
3	Yes	Period numeric Allows selection of time between triggers (10 to 2000 milliseconds).
4	Yes	Number of Transmissions Allows selection of transmissions (No limit, 20, 40, 60, 100, 200, 400, 600, 945, 1000, 2000, 4000, 6000, or 10000).
	Yes	Random Start Active if trigger mode is set to random. The value here is the minimal starting position compare to the reference generator. The range of values for this parameter is from -120000 to 120000 ns.
	Yes	Random Width Active if trigger mode is set to random. The range of values for this parameter is from 0 to 120000 ns.

Figure 3.1.2.4.1.10 illustrates the RTCA/DO-260 Generator Definition Menu. This menu allows the operator to specify the generator parameters for delay triggering.




Figure 3.1.2.4.1.10 – RTCA/DO-260 Generator Definition Menu for Delay Triggering

Diagram Item	Softkey	Function
1	Yes	Generator Allows selection of generator.
2	Yes	Frequency Allows setting the output frequency of the generator.
3	Yes	Power Allows setting the output power of the generator.
4	Yes	Phase Allows setting the output phase of the generator.
5	Yes	Path Allows setting the path of the generator to top or bottom.
6	Yes	Delay Allows setting the delay from the trigger source. If the generator that is being set is the trigger source, this parameter is disabled. The delay value will be either positive or negative in accordance with the setting in the timing definition of delay+ or delay-. The range is from 0 to 120000 nanoseconds in 100 nanosecond steps.
7	Yes	Message Type Allows selecting between Mode S or ATCRBS message. If the generator that is being set is the trigger source, this parameter is disabled and set to Mode S.
8	Yes	Message Definition section Allows the operator to set the message. For Mode S the parameters that can be set are Mode S Address, Mode S Message Type, and whether the data is random excluding the first five bits and the PI field. For ATCRBS the parameters that can be set are Mode A Code or random (2 frame pulses with 5 random data pulses).
9	Yes	Enable Allows enabling or disabling the generator for the test. If the generator selected is the trigger source, this parameter is disabled and the generator is enabled.
10	Yes	Coherence If enabled the two generators of a transmitter module will be in coherence. This will be available when defining Gen A, Gen C, and Gen E.
11	Yes	Random Starting Position Change the starting position of each message from the delay value.

Figure 3.1.2.4.1.11 illustrates the RTCA/DO-260 Generator Definition Menu. This menu allows the operator to specify the generator parameter for walk triggering.




Figure 3.1.2.4.1.11 – RTCA/DO-260 Generator Menu for Walk Triggering

Diagram Item	Softkey	Function
1	Yes	Generator Allows selection of generator.
2	Yes	Frequency Allows setting the output frequency of the generator.
3	Yes	Power Allows setting the output power of the generator.
4	Yes	Phase Allows setting the output phase of the generator.
5	Yes	Path Allows setting the path of the generator to top or bottom.
6	Yes	Delay Allows setting the delay from the trigger source. If the generator that is being set is the trigger source, this parameter is disabled. The delay value will be either positive or negative in accordance with the setting in the timing definition of delay+ or delay-. The

Diagram Item	Softkey	Function
		range is from 0 to 120000 nanoseconds in 100 nanosecond steps.
7	Yes	<p>Message Type</p> <p>Allows selecting between Mode S or ATCRBS message. If the generator that is being set is the trigger source, this parameter is disabled and set to Mode S.</p>
8	Yes	<p>Message Definition section</p> <p>Allows the operator to set the message. For Mode S the parameters that can be set are Mode S Address, Mode S Message Type, and whether the data is random excluding the first five bits and the PI field. For ATCRBS the parameters that can be set are Mode A Code or random (2 frame pulses with 5 random data pulses).</p>
9	Yes	<p>Enable</p> <p>Allows enabling or disabling the generator for the test. If the generator selected is the trigger source, this parameter is disabled and the generator is enabled.</p>
10	Yes	<p>Coherence</p> <p>If enabled the two generators of a transmitter module will be in coherence. This will be available when defining Gen A, Gen C, and Gen E.</p>
11	Yes	<p>Walk</p> <p>Allows enabling or disabling the walk function for the generator. If walk is disable the output will be at the delay parameter specified and will not move. If walk is enable than the message will start at the delay parameter and move 25 nanoseconds every transmission.</p>

3.1.2.4.2. Block Transmission

Figure 3.1.2.4.2.1 illustrates the TTG-7000 Block Transmission Menu. The TTG-7000 Block Transmission Menu allows the user to define a block of 1090/1030 messages to transmit with a specific timing and at a specified periodic timing.




Figure 3.1.2.4.2.1 – TTG7000 Block Transmission Menu

Diagram Item	Softkey	Function
1	No	Illustrates the message sequence defined for the block.
	Yes	Load Load a Block Transmission sequence from the internal data location or an external drive if present.
	Yes	Save Save a Block Transmission sequence to the internal data location or an external drive if present.
	Yes	Add Message Adds a new message to the sequence and open Add Message Menu to allow definition of the message.

Diagram Item	Softkey	Function
	Yes	Message Details Opens Message Detail Menu to allow modifying the parameters of the selected message.
	Yes	Remove Removes the selected message from the block sequence.
	Yes	Reset Clears the entire block sequence.
	Yes	Transmission Start/Stop Allows starting and stopping the block transmissions.
	Yes	Frame Period Sets the frame period for the block transmissions. Range from 10 milliseconds to 50 seconds.
	Yes	Mode Set to continuous transmissions or interrupted. If interrupted is selected than two more softkeys are displayed (Hit and Miss)
	Yes	No Limit Transmission If no limit transmission is set then TTG7000 will continue to transmit block sequences until the transmission stop command or switch is turned off. If no limit transmission is turned off, then the softkey for Number of Transmissions will be illustrated.
	Yes	Hit Sets how many groups of block sequences will be transmitted before the next miss group. Range 0 to 20.
	Yes	Miss Sets how many groups of block sequences will not be transmitted before the next hit group. Range 0 to 20.
	Yes	Number of Transmissions Sets the number of block sequences to transmit. Range from 1 to 50000.

Figure 3.1.2.4.2.2 illustrates the TTG-7000 Block Transmission Add Message Menu. This menu allows the user to define the parameters for the new message that was added. The menu allows selection of 1030/1090 messages, Mode S/ATCRBS, power, phase, and transmission time.




Figure 3.1.2.4.2.2 – TTG7000 Block Transmission Add Message Menu

Diagram Item	Softkey	Function
	Yes	Message Type Allows selection of Mode S Interrogation, Mode S Replies, ATCRBS Interrogation, or ATCRBS Replies.
	Yes	Message Name Subcategory of message within the Message Type selected. For example, Message Type is Mode S Replies, then Message Name could be DF0, DF4, DF5, DF16, etc.
	Yes	Frame Details Opens a new menu that illustrates the detail information about the message defined.
	Yes	Address Originator The value used in the AP field to generate the PI field of a Mode S reply. [DF Messages]
	Yes	Transponder Address The value used in the AP field to generate the PI field of a Mode S interrogation. [UF Messages]
	Yes	Phase Allows setting the phase of the message from 0 to 359 degrees.

Diagram Item	Softkey	Function
	Yes	Power Level Allows setting the power level of the message.
	Yes	Time Allows setting the transmission time within the block of messages.

Figure 3.1.2.4.2.3 illustrates the TTG-7000 Block Transmission Message Frame Detail Menu. This menu allows the user to update the fields of the selected message.

Name	Value	Units	LSB	Description	Low	High	Invalid
DF	0	N/A	0		0	0	False
VS	0	N/A	0	Airborne	0	1	False
CC	0	N/A	0	Crosslink Not Supported	0	1	False
Spare	0	N/A	0		0	0	False
SL	0	N/A	0	No TCAS Sensitivity Level	0	7	False
Spare	0	N/A	0		0	0	False
RI	0	N/A	0	Non on-board TCAS	0	15	False
Spare	0	N/A	0		0	0	False
AC	No Data	N/A	1		-1300	128000	True

Frame Details Menu

Local Remote

▲

DF

0

▲ ▼

VS

Airborne

Airborne

▲ ▼

▼

↩ ➡

Figure 3.1.2.4.2.3 – TTG7000 Block Transmission Frame Detail Menu

3.1.2.5. TCAS Scenario Menu

Figure 3.1.2.5.1 illustrates the TTG-7000 TCAS Scenario Menu. The TCAS Scenario Menu allows the user to define a specific scenario for testing a TCAS System. The user can define thirty two (32) dynamic and five hundred and sixty eight (568) static intruders. The user can define a Mode S Only, Mode S Extended (ADS-B), TIS-B (DF18), and ATCRBS (Mode A/C) intruders.




Figure 3.1.2.5.1 – TTG-7000 TCAS Scenario Menu

Diagram Item	Softkey	Function
1	No	Scenario Current Run Time.
2	Yes	Scenario Time Maximum scenario time (duration) is 6550 seconds.
3	No	Number of dynamic intruders enabled.
4	Yes	Number of dynamic intruders Maximum number of dynamic intruders is 32.

Diagram Item	Softkey	Function
5	Yes	Number of static intruders Maximum number of static intruders is 568.
6	No	Number of static intruders enabled.
7	Yes	Number of Ground Stations Maximum number of ground stations is 15.
8	No	Number of Ground Stations enabled.
9	Yes	Number of Video Blocks. Maximum number of Video Blocks is 12.
10	Yes	Capture Squitters and Datalogging Allows the user to log all the messages received during the scenario according to the message mask assigned in the Receiver menu. The data log is reset at the start of scenario.
11	Yes	Fruit enable/disable
12	Yes	ATE Line Synchronization If synchronization is enabled, then all scenario run time is synchronized to TCAS TISI sequence. (ATE Lines need to be attached to test set)
13	Yes	Slant Range. If enabled the TTG-7000 calculates the range using the intruder range, intruder altitude, and own aircraft altitude. If disabled the range is the horizontal range that is defined in the intruder definition.
14	No	Number of Video Blocks enabled.
15	Yes	Power Mode. The user can select between high or low power modes. High power mode allows output of 1 to -69 dBm and low power allows -20 to -90 dBm.
16	Yes	Antenna Configuration Allows dual antenna; top only or bottom only setup.
17	Yes	Squitter Spacing. Allows setting the time spacing between squitters from 200 to 500 microseconds. Default is 200 microseconds. If random squitter spacing is enabled, then the TTG-7000 will generate the squitters with random spacing between 150 and 500 microseconds. Note: if random squitter spacing is selected than the number of intruders can not be at set at the maximum number.
18	Yes	Coordination Repetition Interval Time interval between coordination interrogations if TCAS system does not reply. The maximum number of repetition is ten (10) interrogations. Interval range from 1000 to 65000 microseconds. Default is 10000 microseconds.
19	Yes	Own Aircraft Source

Diagram Item	Softkey	Function
		Allows the own aircraft data to be entered manually, through 429, external (TCP/IP), or from UUT squitters.
20	Yes	Static mode Allows the dynamic intruders to stay active after the runtime has reached the scenario time with their last position.
21	Yes	Special Test Combobox [Customer Specific]
22	Yes	Waypoint Definition. Allows setting waypoints either by time, location (latitude and longitude realistic airplane simulation) or forced trajectory (latitude and longitude pass over).
23	Yes	Video Data Bit Period. Allows setting the period of a Video Block Data Bit to either 25 or 50 nanoseconds.
24	Yes	Recompile after load. If this is enabled, when a scenario file is loaded all the Mode S Squitters are recompiled.
25	Yes	Manual Whisper Shout. If this is enabled the user will have to enter the whisper shout level for any ATCRBS intruder. If this is disabled, then the whisper shout level will be determined by OEM and range of intruder.
	Yes	Load Opens a file dialog to allow the user to load a saved scenario configuration.
	Yes	Save Allows storing the current scenario configuration to a file.
	Yes	Reset Clears all intruders, ground stations, and video blocks data.
	Yes	Intruders Opens the intruder definition menu. Mode S Dynamic Mode S Static Mode C Dynamic Mode C Static Mode S Extended Dynamic Mode S Extended Static TIS-B Only Dynamic TIS-B Only Static ADS-R Dynamic ADS-R Static
	Yes	Scenario Stop/Start
	Yes	ATCRBS Pulse Information Opens ATCRBS Pulse definition menu.

Diagram Item	Softkey	Function
	Yes	Mode S Pulse Information Opens Mode S Pulse definition menu.
	Yes	Display Menu

3.1.2.5.1. Static Mode S TCAS Only Definition Menu

Figure 3.1.2.5.1.1 illustrates the TTG-7000 Static Mode S TCAS Only Definition Menu. The Static Mode S TCAS Only Definition Menu allows the user to define a static Mode S only (non ADS-B) intruder.




Figure 3.1.2.5.1.1 – Static Mode S TCAS Only Menu

Diagram Item	Softkey	Function
1	Yes	Type Dynamic or Static
2	Yes	Number Dynamic: 1-32; Static: 1-568
3	Yes	Mode Mode S TCAS Only, Mode S Extended, Mode C, TIS-B, or ADS-R

Diagram Item	Softkey	Function
4	Yes	Tx Channel User can select from one of three possible transmitters.
5	Yes	Altitude Binary range from -1000 to 50175 feet in 25 feet steps. Gilham range from -1000 to 126700 feet in 100 feet steps.
6	Yes	Bearing (Phase) Range 0 – 359 degrees in 1 degree steps.
7	Yes	Range Range from 0 to 160 nautical miles.
8	Yes	Latitude. Range from -90 to 90 degrees.
9	Yes	Longitude. Range from -180 to 180 degrees.
10	Yes	Reply Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
11	Yes	Reply Antenna Bottom Only, Top Only, Alternating, Both, or By Altitude
12	Yes	Squitter Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
13	Yes	Squitter Antenna Top Only, Bottom Only, or Both
14	Yes	Start/Stop Time.
15	Yes	Enable If checked then test set will transmit the required messages for this intruder.
16	Yes	Reply If checked then the intruder will reply to interrogations.
17	Yes	Ground Allows the user to set the intruder to ground.
18	Yes	Squitter Enable.
19	Yes	Crosslink Capability
20	Yes	Mode S Address Mode S Address expressed in hexadecimal.
21	Yes	Squitter Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
22	Yes	Reply Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
23	Yes	Altitude Mode Gilham or Binary
24	Yes	Mode A Code.

Diagram Item	Softkey	Function
25	Yes	Utility Message (UM) Field.
26	Yes	Downlink Request (DR) Field.
27	Yes	Flight Status (FS) Field.
28	Yes	Transponder Capability (CA) Field.
29	Yes	SL (Sensitivity Level)
30	Yes	RI (AQ = 0)
31	Yes	RI (AQ = 1)
	Yes	Coordination Message Definition
	Yes	Broadcast Message Definition
	Yes	DF16 Reply Message Menu
	Yes	UF0 Message Menu
	Yes	One Shot Data

3.1.2.5.1.1. Coordination Message Menu

Figure 3.1.2.5.1.1.1 illustrates the TTG-7000 Coordination Message Definition Menu. The Coordination Message Definition Menu allows the user to define the coordination message of a Mode S intruder.




Figure 3.1.2.5.1.1.1 – Coordination Message Menu

Diagram Item	Softkey	Function
1	No	Data grid of all defined coordination messages.
	Yes	Add Adds a new coordination message.
	Yes	Remove Removes the selected coordination message.
	Yes	Start Time Allows setting the start time of the selected coordination message.
	Yes	Stop Time Allows setting the stop time of the selected coordination message.

Diagram Item	Softkey	Function
	Yes	Reply Length Allows setting the RL bit of the coordination message.
	Yes	Acquisition Special Allows setting the AQ bit of the coordination message.
	Yes	Enable Allows enabling or disabling coordination messages.
	Yes	Intruder Initiated If yes (on) then the intruder sends the coordination message at the appropriate time specified. If no (off) then the intruder waits for an UUT coordination message at the appropriate time before transmitting a coordination message.
	Yes	MU Field Menu See Figure 3.1.2.5.1.1.2




Figure 3.1.2.5.1.1.2 – Coordination Message MU Field Menu

Diagram Item	Softkey	Function
1	No	Breakdown of the coordination message.
	Yes	MU-MTB
	Yes	MU-CVC
	Yes	MU-VRC
	Yes	MU-CHC
	Yes	MU-HRC
	Yes	MU-HSB
	Yes	MU-VSB
	Yes	MU-MID

3.1.2.5.1.2. Broadcast Message

Figure 3.1.2.5.1.2.1 illustrates the TTG-7000 Broadcast Message Definition Menu. The Broadcast Message Definition Menu allows the user to define the broadcast message of a Mode S intruder.




Figure 3.1.2.5.1.2.1 – Broadcast Message Menu

Diagram Item	Softkey	Function
1	No	Data grid of all defined broadcast messages.
	Yes	Add Adds a new broadcast message.
	Yes	Remove Removes the selected broadcast message.
	Yes	Start Time Allows setting the start time of the selected broadcast message.
	Yes	Stop Time Allows setting the stop time of the selected broadcast message.

Diagram Item	Softkey	Function
	Yes	Reply Length Allows setting the RL bit of the broadcast message.
	Yes	Acquisition Special Allows setting the AQ bit of the broadcast message.
	Yes	Enable Allows enabling or disabling broadcast messages.
	Yes	MU Field Menu See Figure 3.1.2.5.1.2.2




Figure 3.1.2.5.1.2.2 – Broadcast Message MU Field Menu

Diagram Item	Softkey	Function
1	No	Breakdown of the Broadcast message.
	Yes	MU-MTB
	Yes	MU-CVC
	Yes	MU-VRC
	Yes	MU-CHC
	Yes	MU-HRC

Diagram Item	Softkey	Function
	Yes	MU-HSB
	Yes	MU-VSB
	Yes	MU-MID

3.1.2.5.1.3. Coordination Replies (DF16 Replies)

Figure 3.1.2.5.1.3.1 illustrates the TTG-7000 Coordination Reply Message Definition Menu. The Coordination Reply Message Definition Menu allows the user to define the coordination reply message of a Mode S intruder.




Figure 3.1.2.5.1.3.1 – Coordination Reply Message Menu

Diagram Item	Softkey	Function
1	No	Data grid of all defined coordination replies messages.
	Yes	Add Adds a new coordination reply.
	Yes	Remove Removes the selected coordination reply.
	Yes	Start Time Allows setting the start time of the selected coordination replies message.
	Yes	Stop Time Allows setting the stop time of the selected coordination replies message.
	Yes	Enable

Diagram Item	Softkey	Function
		Allows enabling or disabling coordination replies messages.
	Yes	MU Field Menu See Figure 3.1.2.5.1.3.2

Name	Value	Units	LSB	Description	Low	High	Invalid
MV-VDS	48	N/A	0		0	255	False
MV-ARA	0	N/A	0		0	16383	False
MV-RAC	0	N/A	0		0	15	False
MV-RAT	0	N/A	0		0	1	False
MV-MTE	0	N/A	0		0	1	False
MV-Reserved	00	N/A	0		00	255	False
MV-Reserved	00	N/A	0		00	255	False
MV-Reserved	00	N/A	0		00	255	False
MV-Reserved	0	N/A	0		0	15	False

DF16 Reply MV Fields Menu

Local Remote

MV-VDS

48

MV-ARA

0

MV-RAC

0

Figure 3.1.2.5.1.3.2 – Coordination Reply Message MV Field Menu

Diagram Item	Softkey	Function
1	No	Breakdown of the coordination reply message.
	Yes	MV-VDS
	Yes	MV-ARA
	Yes	MV-RAC
	Yes	MV-RAT
	Yes	MV-MTE

3.1.2.5.1.4. UF0 Messages

Figure 3.1.2.5.1.4.1 illustrates the TTG-7000 UF0 Message Definition Menu. The UF0 Message Definition Menu allows the user to define the UF0 interrogation messages of a Mode S intruder.




Figure 3.1.2.5.1.4.1 – UF0 Message Menu

Diagram Item	Softkey	Function
1	No	Data grid of all defined UF0 messages.
	Yes	Add Adds a new UF0 interrogation.
	Yes	Remove Removes the selected UF0 interrogation.
	Yes	Start Time Allows setting the start time of the selected UF0 message.
	Yes	Stop Time

Diagram Item	Softkey	Function
		Allows setting the stop time of the selected UF0 message.
	Yes	Reply Length Allows setting the RL bit of the UF0 message.
	Yes	Acquisition Special Allows setting the AQ bit of the UF0 message.
	Yes	BDS Allows setting the BDS register of the UF0 message.
	Yes	Enable Allows enabling or disabling UF0 messages.

3.1.2.5.2. Dynamic Mode S TCAS Only Definition Menu

Figure 3.1.2.5.2.1 illustrates the TTG-7000 Dynamic Mode S TCAS Only Definition Menu. The Dynamic Mode S TCAS Only Definition Menu allows the user to define all the parameters for a dynamic Mode S intruder.




Figure 3.1.2.5.2.1 – Dynamic Mode S Only Menu

Diagram Item	Softkey	Function
1	Yes	Type Dynamic or Static
2	Yes	Number Dynamic: 1-32; Static: 1-568
3	Yes	Mode Mode S TCAS Only, Mode S Extended, Mode C, TIS-B, or ADS-R
4	Yes	Tx Channel

Diagram Item	Softkey	Function
		User can select from one of three possible transmitters.
5	Yes	Altitude Binary range from -1000 to 50175 feet in 25 feet steps. Gilham range from -1000 to 126700 feet in 100 feet steps.
6	Yes	Bearing (Phase) Range 0 – 359 degrees in 1 degree steps.
7	Yes	Range Range from 0 to 160 nautical miles.
8	Yes	Latitude. Range from -90 to 90 degrees.
9	Yes	Longitude. Range from -180 to 180 degrees.
10	Yes	Vertical Speed Range from – 32576 to 32576 ft/min in 64 ft/min steps.
11	Yes	Velocity Range 0 to 2000 knots.
12	Yes	Track Angle Value range from -180 to 180 degrees in 1 degree steps.
13	Yes	Reply Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
14	Yes	Reply Antenna Bottom Only, Top Only, Alternating, Both, or By Altitude
15	Yes	Squitter Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
16	Yes	Squitter Antenna Top Only, Bottom Only, or Both
17	Yes	Start and Stop This time is when the intruder will be present.
18	Yes	Reply If checked then the intruder will reply to interrogations.
19	Yes	Enable If checked then test set will transmit the required messages for this intruder.
20	Yes	Ground Allows the user to set the intruder to ground.
21	Yes	Squitter If enabled squitter are active.
22	Yes	Crosslink Capability

Diagram Item	Softkey	Function
23	Yes	Mode S Address Mode S Address expressed in hexadecimal.
24	Yes	Squitter Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
25	Yes	Reply Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
26	Yes	Altitude Mode Gilham or Binary
27	Yes	Mode A Code.
28	Yes	Utility Message (UM) Field.
29	Yes	Downlink Request (DR) Field.
30	Yes	Flight Status (FS) Field.
31	Yes	SL (Sensitivity Level)
32	Yes	RI (AQ = 0)
33	Yes	RI (AQ = 1)
34	Yes	Transponder Capability (CA) Field.
	Yes	Coordination Message Definition
	Yes	Broadcast Message Definition
	Yes	DF16 Reply Message Menu
	Yes	UF0 Message Menu
	Yes	One Shot Data
	Yes	Waypoints

3.1.2.5.3. Static Mode C Definition Menu

Figure 3.1.2.5.3.1 illustrates the TTG-7000 Static Mode C Definition Menu. The Static Mode C Definition Menu allows the user to define all the parameters for static Mode C intruder.




Figure 3.1.2.5.3.1 – Static Mode C Menu

Diagram Item	Softkey	Function
1	Yes	Start and Stop Time
2	Yes	Type Dynamic or Static
3	Yes	Number Dynamic: 1-32; Static: 1-568
4	Yes	Mode Mode S TCAS Only, Mode S Extended, Mode C, or TIS-B Only
5	Yes	Tx Channel

Diagram Item	Softkey	Function
		User can select from one of three possible transmitters.
6	Yes	Altitude Gilham range from -1000 to 126700 feet in 100 feet steps.
7	Yes	Bearing (Phase) Range 0 – 359 degrees in 1-degree steps.
8	Yes	Range Range from 0 to 160 nautical miles.
9	Yes	Latitude. Range from -90 to 90 degrees.
10	Yes	Longitude. Range from -180 to 180 degrees.
11	Yes	Reply Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
12	Yes	Reply
13	Yes	Enable If enabled then test set will transmit the required messages for this intruder.
14	Yes	Altitude Report If enabled the altitude code pulses are transmitted with the framing pulses. If disabled only the framing pulses are transmitted.
15	Yes	Reply Quadrant WS1 Forward, Right, After, Left, Any, or By Location
16	Yes	Reply Antenna WS1 Top Only, Bottom Only, Both, or By Altitude
17	Yes	Whisper Shout Level 1
18	Yes	Reply Quadrant WS2 Forward, Right, After, Left, Any, or By Location
19	Yes	Reply Antenna WS2 Top Only, Bottom Only, Both, or By Altitude
20	Yes	Whisper Shout Level 2
21	Yes	Mode A Code

3.1.2.5.4. Dynamic Mode C Definition Menu

Figure 3.1.2.5.4.1 illustrates the TTG-7000 Dynamic Mode C Definition Menu. The Dynamic Mode C Definition Menu allows the user to define all the parameters for a dynamic Mode C intruder.




Figure 3.1.2.5.4.1 – Dynamic Mode C Menu

Diagram Item	Softkey	Function
1	Yes	Type Dynamic or Static
2	Yes	Number Dynamic: 1-32; Static: 1-568
3	Yes	Mode Mode S TCAS Only, Mode S Extended, Mode C, or ADS-B Only
4	Yes	Tx Channel

Diagram Item	Softkey	Function
		User can select from one of three possible transmitters.
5	Yes	Altitude Gilham range from -1000 to 126700 feet in 100 feet steps.
6	Yes	Bearing (Phase) Range 0 – 359 degrees in 1-degree steps.
7	Yes	Range Range from 0 to 160 nautical miles.
8	Yes	Latitude. Range from -90 to 90 degrees.
9	Yes	Longitude. Range from -180 to 180 degrees.
10	Yes	Vertical Speed Range from – 32576 to 32576 ft/min in 64 ft/min steps
11	Yes	Velocity Range 0 to 2000 knots.
12	Yes	Track Angle Value range from 0 to 359 degrees in 1-degree steps.
13	Yes	Reply Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
14	Yes	Start and Stop Time
15	Yes	Reply
16	Yes	Enable If enabled then test set will transmit the required messages for this intruder.
17	Yes	Altitude Report If enabled the altitude code pulses are transmitted with the framing pulses. If disable only the framing pulses are transmitted.
18	Yes	Reply Quadrant WS1 Forward, Right, After, Left, Any, or By Location
19	Yes	Reply Antenna WS1 Top Only, Bottom Only, Both, or By Altitude
20	Yes	Whisper Shout Level 1
21	Yes	Reply Quadrant WS2 Forward, Right, After, Left, Any, or By Location
22	Yes	Reply Antenna WS2 Top Only, Bottom Only, Both, or By Altitude
23	Yes	Whisper Shout Level 2
24	Yes	Mode A Code
	Yes	Waypoints

3.1.2.5.5. Static Mode S Extended Definition Menu

Figure 3.1.2.5.5.1 to 3.1.2.5.5.9 illustrates the TTG-7000 Static Mode S Extended Definition Menu. The Static Mode S Extended Definition Menu allows the user to define all the parameters for static Mode S Extended intruder.




Figure 3.1.2.5.5.1 – Static Mode S Extended Menu

Diagram Item	Softkey	Function
1	Yes	Type Dynamic or Static
2	Yes	Number Dynamic: 1-32; Static: 1-568
3	Yes	Mode

Diagram Item	Softkey	Function
		Mode S TCAS Only, Mode S Extended, Mode C, ADS-B Only
4	Yes	Tx Channel User can select from one of three possible transmitters.
5	Yes	Altitude Gilham range from -1000 to 126700 feet in 100 feet steps.
6	Yes	Bearing (Phase) Range 0 – 359 degrees in 1-degree steps.
7	Yes	Range Range from 0 to 160 nautical miles.
8	Yes	Latitude. Range from -90 to 90 degrees.
9	Yes	Longitude. Range from -180 to 180 degrees.
10	Yes	Vertical Speed Range from – 32576 to 32576 ft/min in 64 ft/min steps
11	Yes	Velocity Range 0 to 2000 knots.
12	Yes	Track Angle Value range from 0 to 359 degrees in 1-degree steps.
13	Yes	Reply Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
14	Yes	Reply Antenna Top Only, Bottom Only, Alternating, Both, or By Altitude
15	Yes	Squitter Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
16	Yes	Squitter Antenna Top Only, Bottom Only, or Both
17	Yes	Start and Stop Time
18	Yes	Enable If enabled then test set will transmit the required messages for this intruder.
19	Yes	Reply
20	Yes	Altitude Report If enabled the altitude code will be present in the DF0 reply. If disabled the altitude code will set to 0.
21	Yes	Ground Allows the user to set the intruder to ground.
22	Yes	Squitter If enabled squitter are active.

Diagram Item	Softkey	Function
23	Yes	Crosslink Capability
24	Yes	Hybrid Deviation If enabled allows deviation in altitude, bearing, and range.
25	Yes	DO-260 Mode. Version -, A, or B.
26	Yes	Squitter Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
27	Yes	Reply Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
28	Yes	Mode S Address
29	Yes	Altitude Mode switch Gilham or Binary
30	Yes	Identification Type and Intruder Identification.
31	Yes	Velocity Type
32	Yes	Utility Message (UM)
33	Yes	SL
34	Yes	RI (AQ = 0)
35	Yes	RI (AQ = 1)
36	Yes	RI (DF=16)
37	Yes	Downlink Message (DR)
38	Yes	Flight Status (FS)
39	Yes	Mode A Code
40	Yes	CA Field
	Yes	Hybrid Deviation Values When Hybrid Deviation is enable allows entry of range, bearing, and altitude deviation values.
	Yes	CPR Encoding Odd/Even, Odd only, or Even only
	Yes	Mode S Squitters
	Yes	Coordination Message Definition
	Yes	Broadcast Message Definition
	Yes	DF16 Reply Message Menu
	Yes	UF0 Message Menu

3.1.2.5.5.1. Mode S Squitter Definition

Figure 3.1.2.5.5.1 illustrates the TTG-7000 Mode S Squitter Definition Menu. The Mode S Squitter Definition Menu allows the user to define all the parameters for a Mode S ADS-B intruder.




Figure 3.1.2.5.5.1 – Mode S Squitter Definition Menu

Diagram Item	Softkey	Function
1	No	Data Grid of the current defined squitters
	Yes	ME Field Opens specific squitter definition menu. Position Squitter Velocity Squitter Ident Squitter
	Yes	BDS Register Number Menu

3.1.2.5.5.2. Position Squitter Definition Menu

Figure 3.1.2.5.5.2.1 illustrates the TTG-7000 Position Squitter Definition Menu. The Position Squitter Definition Menu allows the user to define all the parameters for a position squitter.

Name	Value	Units	LSB	Description	Low	High	Invalid
ME - Format Type Code	9	N/A	0		0	22	False
ME - Surveillance Status	0	N/A	0		0	3	False
ME - Single Antenna Flag(SAF)	0	N/A	0		0	1	False
ME - Altitude	1000	ft	1		-1000	50175	False
ME - Time	0	N/A	0		0	1	False
ME - CPR Format	0	N/A	0		0	1	False
ME - Latitude	43.618973	deg	0		-90	90	False
ME - Longitude	1.372077	deg	0		-180	180	False

Figure 3.1.2.5.5.2.1 – Position Squitter Definition Menu

Diagram Item	Softkey	Function
1	No	Breakdown of the Position Squitter
	Yes	Format Type Code
	Yes	Surveillance Status
	Yes	Single Antenna Flag
	Yes	Altitude
		Allows setting invalid/no data
	Yes	Time Bit
	Yes	CPR Format
	Yes	Latitude
	Yes	Longitude

3.1.2.5.5.3. Velocity Squitter Definition Menu

Figure 3.1.2.5.5.3.1 illustrates the TTG-7000 Velocity Squitter Definition Menu. The Velocity Squitter Definition Menu allows the user to define all the parameters for a velocity squitter.

Name	Value	Units	LSB	Description	Low	High	Invalid
ME - Format Type Code	19	N/A	0		19	19	False
ME - SubType	1	N/A	0		1	1	False
ME - Intent Change Flag	0	N/A	0		0	1	False
ME - IFR Capability Flag	0	N/A	0		0	1	False
ME - NUCr	1	N/A	0		0	4	False
ME - Direction E/W	0	N/A	0		0	1	False
ME - E/W Velocity	0	kts	1		0	1023	False
ME - Direction N/S	0	N/A	0		0	1	False
ME - N/S Velocity	0	kts	1		0	1023	False

Figure 3.1.2.5.5.3.1 – Velocity Squitter Definition Menu

Diagram Item	Softkey	Function
1	No	Breakdown of the Velocity Squitter
	Yes	Format Type Code
	Yes	Sub Type
	Yes	Intent Change Flag
	Yes	IFR Capability Flag
	Yes	Navigation Accuracy
	Yes	East/Weat Direction
	Yes	East/Velocit
		Allows setting invalid/no data
	Yes	North/South Direction
	Yes	North/South Velocity
		Allows setting invalid/no data

Diagram Item	Softkey	Function
	Yes	Source Bit
	Yes	Sign Bit
	Yes	Vertical Rate Allows setting invalid/no data
	Yes	Difference Sign Bit
	Yes	Geometric Height Difference Allows setting invalid/no data
	Yes	Magnetic Heading Status Bit
	Yes	Magnetic Heading
	Yes	Airspeed Type
	Yes	Vertical Rate Source Bit
	Yes	Vertical Rate Sign Bit
	Yes	Vertical Rate Allows setting invalid/no data
	Yes	Turn Indicator

3.1.2.5.5.4. Ident Squitter Definition Menu

Figure 3.1.2.5.5.4.1 illustrates the TTG-7000 Identification Squitter Definition Menu. The Identification Squitter Definition Menu allows the user to define all the parameters for an Ident squitter.

Name	Value	Units	LSB	Description	Low	High	Invalid
ME - Type	4	N/A	1		1	4	False
ME - Aircraft Category	4	N/A	1		0	7	False
ME - Character #1	S	N/A	1			Z	False
ME - Character #2	T	N/A	1			Z	False
ME - Character #3	A	N/A	1			Z	False
ME - Character #4	T	N/A	1			Z	False
ME - Character #5	0	N/A	1			Z	False
ME - Character #6	0	N/A	1			Z	False
ME - Character #7	1	N/A	1			Z	False

Figure 3.1.2.5.5.4.1 – Ident Squitter Definition Menu

Diagram Item	Softkey	Function
1	No	Breakdown of the Ident Squitter
	Yes	Type
	Yes	Aircraft Category
	Yes	Character #1
	Yes	Character #2
	Yes	Character #3
	Yes	Character #4
	Yes	Character #5
	Yes	Character #6
	Yes	Character #7

Diagram Item	Softkey	Function
	Yes	Character #8

3.1.2.5.5.5. BDS Register Definition Menu

Figure 3.1.2.5.5.5.1 illustrates the TTG-7000 BDS Register Definition Menu. The BDS Register Definition Menu allows the user to add or remove BDS registers to a Mode S Extended intruder.




Figure 3.1.2.5.5.5.1 – Ident Squitter Definition Menu

Diagram Item	Softkey	Function
1	No	Data grid of all defined BDS registers
	Yes	Add
	Yes	Remove
	Yes	MV Field Menu

3.1.2.5.6. Dynamic Mode S Extended Definition Menu

Figure 3.1.2.5.6.1 illustrates the TTG-7000 Dynamic Mode S Extended Definition Menu. The Static Mode S Extended Definition Menu allows the user to define all the parameters for a dynamic Mode S Extended intruder.




Figure 3.1.2.5.6.1 – Dynamic Mode S Extended Menu

Diagram Item	Softkey	Function
1	Yes	Type Dynamic or Static
2	Yes	Number

Diagram Item	Softkey	Function
		Dynamic: 1-32; Static: 1-568
3	Yes	Mode Mode S TCAS Only, Mode S Extended, Mode C, TIS-B, or ADS-R
4	Yes	Tx Channel User can select from one of three possible transmitters.
5	Yes	Altitude Binary range from -1000 to 50175 feet in 25 feet steps. Gilham range from -1000 to 126700 feet in 100 feet steps.
6	Yes	Bearing (Phase) Range 0 – 359 degrees in 1-degree steps.
7	Yes	Range Range from 0 to 160 nautical miles.
8	Yes	Latitude Range from -90 to 90 degrees
9	Yes	Longitude Range from -180 to 180 degrees.
10	Yes	Vertical Speed Range from – 32576 to 32576 ft/min in 64 ft/min steps.
11	Yes	Velocity Range 0 to 2000 knots.
12	Yes	Track Angle Value range from -180 to 180 degrees in 1-degree steps.
13	Yes	Reply Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
14	Yes	Reply Antenna Top Only, Bottom Only, Alternating, Both, or By Altitude
15	Yes	Squitter Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
16	Yes	Squitter Antenna Top Only, Bottom Only, or Both
17	Yes	Start/Stop Time. Time intruder is active.
18	Yes	Reply If checked then the intruder will reply to interrogations.
19	Yes	Enable. If checked then test set will transmit the required messages for this intruder.

Diagram Item	Softkey	Function
20	Yes	Altitude Report If enabled the altitude code will be present in the DF0 reply. If disabled the altitude code will set to 0.
21	Yes	Ground Allows the user to set the intruder to ground.
22	Yes	Squitter If enabled squitter are active.
23	Yes	Crosslink Capability
24	Yes	Override Range Calculation
25	Yes	DO-260 Mode Version -, A, or B.
26	Yes	Squitter Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
27	Yes	Reply Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
28	Yes	Mode S Address
29	Yes	Altitude Mode Gilham or Binary
30	Yes	Identification Type and Intruder Identification.
31	Yes	Velocity Type
32	Yes	Utility Message (UM)
33	Yes	SL combobox
34	Yes	RI (AQ = 0) combobox
35	Yes	RI (AQ = 1) combobox
36	Yes	RI (DF=16)
37	Yes	Downlink Message (DR)
38	Yes	Flight Status (FS)
39	Yes	Mode A Code
40	Yes	CA Field
	Yes	Hybrid Deviation Values If hybrid deviation enable allows entry of range, bearing, and altitude deviations.
	Yes	CPR Encoding Odd/Even, Odd only, or Even only
	Yes	Mode S Squitters
	Yes	Coordination Message Definition
	Yes	Broadcast Message Definition
	Yes	DF16 Reply Message Menu
	Yes	UF0 Message Menu
	Yes	Waypoints

3.1.2.5.7. Static TIS-B Definition Menu

Figure 3.1.2.5.7.1 illustrates the TTG-7000 Static TIS-B Definition Menu. The Static TIS-B Definition Menu allows the user to define all the parameters for static TIS-B (DF18) intruder.




Figure 3.1.2.5.7.1 – Static TIS-B Menu

Diagram Item	Softkey	Function
1	Yes	Type Dynamic or Static
2	Yes	Number Dynamic: 1-32; Static: 1-568
3	Yes	Mode Mode S TCAS Only, Mode S Extended, Mode C, TIS-B, or ADS-R
4	Yes	Tx Channel User can select from one of three possible transmitters.

Diagram Item	Softkey	Function
5	Yes	Altitude Binary range from -1000 to 50175 feet in 25 feet steps. Gilham range from -1000 to 126700 feet in 100 feet steps.
6	Yes	Bearing (Phase) Range 0 – 359 degrees in 1-degree steps.
7	Yes	Range Range from 0 to 160 nautical miles.
8	Yes	Latitude Range from -90 to 90 degrees.
9	Yes	Longitude Range from -180 to 180 degrees.
10	Yes	Vertical Speed Range from – 32576 to 32576 ft/min in 64 ft/min steps. Used only for the velocity squitter, since the intruder is static.
11	Yes	Velocity Range 0 to 2000 knots. Used only for the velocity squitter, since the intruder is static.
12	Yes	Track Angle Value range from -180 to 180 degrees in 1-degree steps. Used only for the velocity squitter, since the intruder is static.
13	Yes	Squitter Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
14	Yes	Squitter Antenna Top Only, Bottom Only, or Both
15	Yes	Start/Stop Time.
16	Yes	Enable. If checked then test set will transmit the required messages for this intruder.
17	Yes	Altitude Report If enabled the altitude code will be present in the DF0 reply. If disabled the altitude code will set to 0.
18	Yes	Ground Allows the user to set intruder on the ground.
19	Yes	Squitter If enabled squitter are active.
20	Yes	DO-260 Mode. Version -, A, or B.
21	Yes	Mode S Address
22	Yes	Squitter Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
23	Yes	Altitude Mode Gilham or Binary

Diagram Item	Softkey	Function
24	Yes	Intruder Identification
25	Yes	Vertical Velocity
26	Yes	Velocity Type
27	Yes	Utility Message (UM) Field
28	Yes	Downlink Request (DR) Field
29	Yes	Position Type combobox ADS-B, Fine, or Coarse.
30	Yes	Flight Status (FS) Field
31	Yes	Transponder Capability (CF) Field
	Yes	CPR Encoding Odd/Even, Odd only, or Even only
	Yes	Mode S Squitters

3.1.2.5.8. Dynamic TIS-B Definition Menu

Figure 3.1.2.5.8.1 illustrates the TTG-7000 Dynamic TIS-B Only Definition Menu. The Dynamic TIS-B Definition Menu allows the user to define all the parameters for a dynamic TIS-B (DF18) intruder.




Figure 3.1.2.5.8.1 – Dynamic TIS-B Menu

Diagram Item	Softkey	Function
1	Yes	Type Dynamic or Static
2	Yes	Number Dynamic: 1-32; Static: 1-568
3	Yes	Mode Mode S TCAS Only, Mode S Extended, Mode C, TIS-B, ADS-R

Diagram Item	Softkey	Function
4	Yes	Tx Channel User can select from one of three possible transmitters.
5	Yes	Altitude Binary range from -1000 to 50175 feet in 25 feet steps. Gilham range from -1000 to 126700 feet in 100 feet steps.
6	Yes	Bearing (Phase) Range 0 – 359 degrees in 1-degree steps.
7	Yes	Range Range from 0 to 160 nautical miles.
8	Yes	Latitude Range from -90 to 90 degrees.
9	Yes	Longitude Range from -180 to 180 degrees.
10	Yes	Vertical Speed Range from – 32576 to 32576 ft/min in 64 ft/min steps.
11	Yes	Velocity Range 0 to 2000 knots.
12	Yes	Track Angle Value range from -180 to 180 degrees in 1-degree steps.
13	Yes	Squitter Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
14	Yes	Squitter Antenna Top Only, Bottom Only, or Both
15	Yes	Start/Stop Time.
16	Yes	Enable. If checked then test set will transmit the required messages for this intruder.
17	Yes	Altitude Report If enabled the altitude code will be present in the DF0 reply. If disabled the altitude code will set to 0.
18	Yes	Ground Allows the user to set intruder on the ground.
19	Yes	Squitter Enable.
20	Yes	DO-260 Mode -,A, or B.
21	Yes	Mode S Address
22	Yes	Squitter Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
23	Yes	Altitude Code switch. Gilham or Binary
24	Yes	Intruder Identification

Diagram Item	Softkey	Function
25	Yes	Vertical Velocity Source Geometric or Barometric
26	Yes	Velocity Type
27	Yes	Utility Message (UM) Field
28	Yes	Downlink Request (DR) Field
29	Yes	Position Squitter Type ADS-B, Fine or Coarse
30	Yes	Flight Status (FS) Field
31	Yes	Transponder Capability (CA) Field
	Yes	CPR Encoding Odd/Even, Odd only, or Even only
	Yes	Mode S Squitters
	Yes	Waypoints

3.1.2.5.9. Static ADS-R Definition Menu

Figure 3.1.2.5.9.1 illustrates the TTG-7000 Static ADS-R Definition Menu. The Static ADS-R Definition Menu allows the user to define all the parameters for static ADS-R (DF18) intruder.




Figure 3.1.2.5.9.1 – Static ADS-R Menu

Diagram Item	Softkey	Function
1	Yes	Type Dynamic or Static.
2	Yes	Number Dynamic: 1-32; Static: 1-568.
3	Yes	Mode Mode S TCAS Only, Mode S Extended, Mode C, TIS-B, ADS-R.
4	Yes	Tx Channel

Diagram Item	Softkey	Function
		User can select from one of three possible transmitters.
5	Yes	Altitude Binary range from -1000 to 50175 feet in 25 feet steps. Gilham range from -1000 to 126700 feet in 100 feet steps.
6	Yes	Bearing (Phase) Range 0 – 359 degrees in 1-degree steps.
7	Yes	Range Range from 0 to 160 nautical miles.
8	Yes	Latitude Range from -90 to 90 degrees.
9	Yes	Longitude Range from -180 to 180 degrees.
10	Yes	Vertical Speed Range from – 32576 to 32576 ft/min in 64 ft/min steps.
11	Yes	Velocity Range 0 to 2000 knots.
12	Yes	Track Angle Value range from -180 to 180 degrees in 1-degree steps.
13	Yes	Squitter Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
14	Yes	Squitter Antenna Top Only, Bottom Only, or Both
15	Yes	Start/Stop Time.
16	Yes	Enable. If checked then test set will transmit the required messages for this intruder.
17	Yes	Altitude Report If enabled the altitude code will be present in the DF0 reply. If disabled the altitude code will set to 0.
18	Yes	Ground Allows the user to set intruder on ground.
19	Yes	Squitter Enable.
20	Yes	DO-260 Mode -,A, or B.
21	Yes	Mode S Address
22	Yes	Squitter Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
23	Yes	Altitude Code Gilham or Binary
24	Yes	Intruder Identification
25	Yes	Mode A Code

Diagram Item	Softkey	Function
26	Yes	Velocity Type
27	Yes	Utility Message (UM) Field
28	Yes	IMF Field
29	Yes	Downlink Request (DR) Field
30	Yes	Flight Status (FS) Field
31	Yes	Transponder Capability (CA) Field
	Yes	CPR Encoding Odd/Even, Odd only, or Even only
	Yes	Mode S Squitters

3.1.2.5.10. Dynamic ADS-R Definition Menu

Figure 3.1.2.5.10.1 illustrates the TTG-7000 Dynamic ADS-R Definition Menu. The Dynamic ADS-R Definition Menu allows the user to define all the parameters for a dynamic ADS-R (DF18) intruder.




Figure 3.1.2.5.10.1 – Dynamic ADS-R Menu

Diagram Item	Softkey	Function
1	Yes	Type Dynamic or Static
2	Yes	Number Dynamic: 1-32; Static: 1-568
3	Yes	Mode Mode S TCAS Only, Mode S Extended, Mode C, TIS-B, ADS-R.

Diagram Item	Softkey	Function
4	Yes	Tx Channel User can select from one of three possible transmitters.
5	Yes	Altitude Binary range from -1000 to 50175 feet in 25 feet steps. Gilham range from -1000 to 126700 feet in 100 feet steps.
6	Yes	Bearing (Phase) Range 0 – 359 degrees in 1-degree steps.
7	Yes	Range Range from 0 to 160 nautical miles.
8	Yes	Latitude Range from -90 to 90 degrees.
9	Yes	Longitude Range from -180 to 180 degrees.
10	Yes	Vertical Speed Range from – 32576 to 32576 ft/min in 64 ft/min steps.
11	Yes	Velocity Range 0 to 2000 knots.
12	Yes	Track Angle Range from -180 to 180 degrees in 1-degree steps.
13	Yes	Squitter Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
14	Yes	Squitter Antenna Top Only, Bottom Only, or Both.
15	Yes	Start/Stop Time.
16	Yes	Enable. If checked then test set will transmit the required messages for this intruder.
17	Yes	Altitude Report If enabled the altitude code will be present in the DF0 reply. If disabled the altitude code will set to 0.
18	Yes	Ground Allows the user to set intruder on ground.
19	Yes	Squitter Enable
20	Yes	DO-260 Mode -,A, or B.
21	Yes	Mode S Address
22	Yes	Squitter Probability Pattern Values: 1.0, 0.8, 0.6, 0.4, 0.2
23	Yes	Altitude Code Gilham or Binary.
24	Yes	Intruder Identification
25	Yes	Mode A Code

Diagram Item	Softkey	Function
26	Yes	Velocity Type
27	Yes	Utility Message (UM) Field
28	Yes	IMF Field
29	Yes	Downlink Request (DR) Field
30	Yes	Flight Status (FS) Field
31	Yes	Transponder Capability (CA) Field
	Yes	CPR Encoding Odd/Even, Odd only, or Even only.
	Yes	Mode S Squitters
	Yes	Waypoints

3.1.2.5.11. TCAS Display Menu

Figure 3.1.2.5.11.1 illustrates the TTG-7000 TCAS Display Menu. The TCAS Display Menu allows the user to view the scenario defined during the tests. The own aircraft information is displayed on the bottom left corner of the display.




Figure 3.1.2.5.11.1 – TCAS Display Menu

Diagram Item	Softkey	Function
1	Yes	Display Area
	Yes	Range Allows selection of display range. (2, 5, 10, 20, 50, or 100 nMi)
	Yes	Caption Allows selection whether or not to display caption next to intruder.
	Yes	Passive Intruder

Diagram Item	Softkey	Function
		Allows the display of the passive intruder squitter position. Passive intruders only shown when Hybrid Deviation is enabled. Passive intruders are the ADS-B information.
	Yes	Active Intruder Allows the display of the active intruder position. Active intruder is the DF reply position.

Note: When an external source (Ethernet or 429) is used the own aircraft information is updated every 5 seconds when a Scenario is not running. The data is updated every second if the scenario is running.

3.1.2.5.12. TCAS Ground Station Menu

Figure 3.1.2.5.12.1 illustrates the TTG-7000 TCAS Ground Station Menu. The TCAS Ground Station Menu allows the user to define up to fifteen (15) different ground stations. The menu also allows the user to define the timeframe and what type of interrogation to perform.




Figure 3.1.2.5.12.1 TCAS Ground Station Menu

Diagram Item	Softkey	Function
1	Yes	Ground Station Range 1 – 15
2	Yes	Interrogation Name This combobox allows selection of a valid UF message.
3	Yes	Starting At Allows setting the initial time that the selected interrogation will be transmitted.
4	Yes	Enable Allows enabling or disabling the current ground station.

Diagram Item	Softkey	Function
5	Yes	Stopping At Allows setting the final time that the selected interrogation will be transmitted.
	Yes	Interrogations Opens a menu that allows changing the contents of the UF messages.

Figure 3.1.2.5.12.2 illustrates the TTG-7000 TCAS Ground Station Interrogations Menu. This menu allows the user to modify the contents of the selected UF message in different time sections.




Figure 3.1.2.5.12.2 TCAS Ground Station Interrogations Menu

Diagram Item	Softkey	Function
1	No	Data grid of all defined UF messages at all timeframes.
	Yes	Add Adds a new time interval.
	Yes	Remove Removes a time interval.

Diagram Item	Softkey	Function
	Yes	Start Time Start time for the selected interval.
	Yes	Stop Time Stop time for the selected interval.
	Yes	Enable Enables or disables transmission during the selected interval.
	Yes	Frame Details Opens a menu that illustrates the details for the selected UF message, in order to modify the contents.

3.1.2.5.13. TCAS ATCRBS Pulse Information Menu

Figure 3.1.2.5.13.1 illustrates the TTG-7000 TCAS ATCRBS Pulse Information Menu. This menu allows the user to modify the width, position, amplitude and visibility of the ATCRBS pulse for a selected generator. The menu also allows changing the rise and fall times for the selected generator.




Figure 3.1.2.5.13.1 TCAS ATCRBS Pulse Information Menu

Diagram Item	Softkey	Function
1	Yes	Tx Channel Gen A, Gen C, or Gen D
2	Yes	Rise/Fall Allows selection of rise and fall time for the selected generator. (50/50, 100/200, 230/230, 600/600 nanoseconds)
3	Yes	Delta Width Allows setting the width of each individual pulse.
4	Yes	Delta Position

Diagram Item	Softkey	Function
		Allows setting the position of each individual pulse.
5	Yes	Delta Amplitude Allows setting the delta amplitude for each individual pulse to 0 or -1 dB.
6	Yes	Enable Allows enabling or disabling each individual pulse.
	Yes	Reset Sets all values back to default.

3.1.2.5.14. TCAS Mode S Pulse Information Menu

Figure 3.1.2.5.14.1 illustrates the TTG-7000 TCAS Mode S Pulse Information Menu. This menu allows the user to modify the width, position, amplitude and visibility of the Mode S preamble pulses for a selected generator. The menu also allows changing the rise and fall times for the selected generator.




Figure 3.1.2.5.14.1 TCAS Mode S Pulse Information Menu

Diagram Item	Softkey	Function
1	Yes	Tx Channel Gen A, Gen C, or Gen D
2	Yes	Rise/Fall Allows selection of rise and fall time for the selected generator. (50/50, 100/200, 230/230, 600/600 nanoseconds)
3	Yes	Delta Width Allows setting the width of each individual pulse.
4	Yes	Delta Position

Diagram Item	Softkey	Function
		Allows setting the position of each individual pulse.
5	Yes	Delta Amplitude Allows setting the delta amplitude for each individual pulse to 0 or -1 dB.
6	Yes	Enable Allows enabling or disabling each individual pulse.
	Yes	Reset Sets all values back to default.

3.1.2.5.15. TCAS Video Blocks Menu

Figure 3.1.2.5.15.1 illustrates the TTG-7000 TCAS Video Blocks Definition Menu. This menu allows the user to define the video block and trigger mechanism to transmit the block. Figure 3.1.2.5.15.1 shows the Mode S trigger source and Figure 3.1.2.5.15.2 shows the ATCRBS trigger source.




Figure 3.1.2.5.15.1 TCAS Video Blocks Definition Menu

Diagram Item	Softkey	Function
1	Yes	Video Block Maximum 12.
2	Yes	Starting At Allows setting the initial time for video block transmission.
3	Yes	Stopping At Allows setting the final time for video block transmission.
4	Yes	Trigger Source

Diagram Item	Softkey	Function
		Allows setting the trigger source to either Mode C or Mode S interrogation.
5	Yes	Tx Channel Allows setting the transmitter to transmit the video block.
6	Yes	Bearing Allows setting the bearing of the transmitter when transmitting the video block.
7	Yes	Range Allows setting the time delay from the trigger.
8	Yes	Altitude Used only if dynamic velocity not 0.
9	Yes	Velocity
10	Yes	Vertical Speed Used only if dynamic velocity not 0.
11	Yes	Track Used only if dynamic velocity not 0.
12	Yes	Reply Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
13	Yes	Reply Antenna Top Only, Bottom Only, Alternating, Both, or By Altitude
14	Yes	Enable Allows enabling or disabling the video block.
15	Yes	Mode S Address
16	Yes	Altitude Code Gilham or Binary
17	Yes	One Shot Video Data
18	Yes	Video Waypoints
19	Yes	Video Data Bits




Figure 3.1.2.5.15.2 TCAS Video Blocks Definition Menu

Diagram Item	Softkey	Function
1	Yes	Video Block Maximum 12
2	Yes	Starting At Allows setting the initial time for video block transmission.
3	Yes	Stopping At Allows setting the final time for video block transmission.
4	Yes	Trigger Source Allows setting the trigger source to either Mode C or Mode S interrogation.
5	Yes	Tx Channel Allows setting the transmitter to transmit the video block.
6	Yes	Bearing Allows setting the bearing of the transmitter when transmitting the video block.
7	Yes	Range

Diagram Item	Softkey	Function
		Allows setting the time delay from the trigger.
8	Yes	Altitude Used only if dynamic velocity not 0.
9	Yes	Velocity
10	Yes	Vertical Speed Used only if dynamic velocity not 0.
11	Yes	Track Used only if dynamic velocity not 0.
12	Yes	Reply Power Low power range -20 to -90 dBm in 1 dB steps. High power range from 1 to -69 dBm.
13	Yes	Reply Antenna Top Only, Bottom Only, Alternating, Both, or By Altitude
14	Yes	Reply Quadrant Forward, Right, After, Left, or Any Quadrant
15	Yes	Enable Allows enabling or disabling the video block.
16	Yes	Whisper Shout Level
17	Yes	One Shot Video Data
18	Yes	Video Waypoints
19	Yes	Video Data Bits

3.1.2.6. TCAS ATE Line Menu

Figure 3.1.2.6.1 illustrates the TTG-7000 TCAS ATE Line Menu. The TCAS ATE Line Menu allows the user to view the information being received via the ATE Lines connector.




Figure 3.1.2.6.1 – TCAS ATE Line Menu

Diagram Item	Softkey	Function
1	No	Data grid of all received ATE Lines
	Yes	Display Display On/Off Mode Update/Continuous Clear Quantity to Show (1 -1000) Refresh
	Yes	Data Logging Pause/Record Export (Future) Import (Future) Clear

Diagram Item	Softkey	Function
	Yes	ATESource Direct Connect/ATE Interface Box

3.1.2.7. TCAS Chamber Mode Menu

Figure 3.1.2.7.1 illustrates the TTG-7000 Chamber Mode Menu. The TCAS Chamber Mode Menu allows the user to set the path loss between the outputs of the TTG-7000C RF Amplifier unit and the TCAS Processor Antenna input port. It also allows the setting of the Fruit power levels.




Figure 3.1.2.7.1 – TCAS Chamber Mode Menu

Diagram Item	Softkey	Function
1	Yes	Path loss for every chamber antenna port 0° - Path Loss for 0° port 45° - Path Loss for 45° port 90° - Path Loss for 90° port 135° - Path Loss for 135° port 180° - Path Loss for 180° port 225° - Path Loss for 225° port 270° - Path Loss for 270° port 315° - Path Loss for 315° port

Diagram Item	Softkey	Function
2	Yes	Fruit power levels Hi Power - Fruit Hi power level Med Power - Fruit Med power level Low Power - Fruit Low power level

3.1.2.8. Measurement Menu

Figure 3.1.2.8.1 and 3.1.2.8.2 illustrates the TTG-7000 Measurement Menu. The Measurement Menu allows the user to view the pulses from the TCAS Processor or Transponder. The Measurement Menu allows the user to make measurements for power, pulsewidth, risetime, falltime, spacing, frequency, and phase.




Figure 3.1.2.8.1 – Scope Menu

Diagram Item	Softkey	Function
1	Yes	Measurement/Scope Allows the user to perform a measurement or set the scope to view a received waveform.
2	Yes	Channel 1 selection
3	Yes	Trigger source Log Video, ATE Line Mode S, ATE Line Mode A, or ATE Line Mode C
4	Yes	Trigger level

Diagram Item	Softkey	Function
		If ATE Line Mode C/Mode A is selected for the trigger source then a combobox to select whisper/shout level is displayed. If Log Video is selected for the trigger source then a slider for power level is displayed. If ATE Line Mode S is selected for trigger source then Mode S Address numeric control is displayed.
5	Yes	Trigger mode Single or Normal
6	Yes	Trigger edge. + or -. Only displayed if trigger source is Log Video.
7	Yes	Waveform graph area. Dragging the mouse or finger on the touchscreen over the axis and graph can change the horizontal/vertical scales and horizontal/vertical positions.
8	Yes	Trigger Antenna Top or Bottom
9	Yes	Sampling timespan. 10, 25, or 100 nanoseconds[100, 40, or 10 MHz)
10	Yes	Receiver Port
11	Yes	Channel 2 selection




Figure 3.1.2.8.2 – Measurement Menu

Diagram Item	Softkey	Function
1	Yes	Measurement/Scope Allows the user to perform a measurement or set the scope to view a received waveform.
2	Yes	Measurement Pulse, Frequency, Phase
3	Yes	Pulse selection
4	Yes	Trigger level If ATE Line Mode C/Mode A is selected for the trigger source then a combobox to select whisper/shout level is displayed. If Log Video is selected for the trigger source then a slider for power level is displayed. If ATE Line Mode S is selected for trigger source then Mode S Address numeric control is displayed.
5	Yes	Trigger mode. Single or Normal
6	Yes	Waveform graph area. Dragging the mouse or finger on the touchscreen over the axis and graph can change the

Diagram Item	Softkey	Function
		horizontal/vertical scales and horizontal/vertical positions.
7	Yes	Trigger source Log Video, ATE Line Mode S, ATE Line Mode A, or ATE Line Mode C.
8	Yes	Receiver Port
9	Yes	Top/Bottom Antenna

3.1.3. Transponder Menu

Figure 3.1.3.1 illustrates the TTG-7000 Transponder Menu.




Figure 3.1.3.1 – Transponder Menu

Diagram Item	Softkey	Function
1	Yes	Settings
2	Yes	Measurements
3	Yes	Receiver Menu
4	Yes	Transponder Tests

3.1.3.1. Transponder Settings

Figure 3.1.3.1.1 illustrates the TTG-7000 Transponder Settings Menu. The Transponder Settings Menu allows the user to configure the Transmitter, Receiver, and Antenna Simulator modules within the test set for transponder tests. This menu is mainly used for testing and troubleshooting of the TTG-7000. For Transponder unit testing, this menu should only be used to set the individual RF generator frequencies.




Figure 3.1.3.1.1 – Transponder Settings Menu

Diagram Item	Softkey	Function
1	Yes	Suppression Out On/Off
2	Yes	Receiver Path Allows the user to select which port to connect the Top/Bottom Receiver. Selections available are Rx T1/B1, Rx T2/B2, Rx T3/B3, Rx T4/B4, Chamber, or Combiner.
3	Yes	Transmitter On/Off
4	Yes	Tx Frequency

Diagram Item	Softkey	Function
		Allows the setting of the Transmitter frequency. Individual setting for each transmitter. Range from 962 to 1213 MHz in 0.1 MHz steps.
5	Yes	Tx Power Allows the setting of the Transmitter power from -20 to -90 dBm in 1 dB steps.
6	Yes	Tx Path Allows setting the Tx path to Top All Ports/Bottom All Ports/Single Port.
7	Yes	Modulation CW/Pulse

3.1.3.2. Transponder Test (Single Interrogation)

Figure 3.1.3.2.1 illustrates the TTG-7000 Transponder Test Menu in Single Interrogation Mode. The Transponder Test Menu in Single Interrogation Mode allows the user to setup the TTG-7000 to transmit a Mode A, Mode C, Mode A All-Call, Mode C All-Call, Mode A/Mode S All-Call, Mode C/Mode S All-Call, Mode S, P1-P2, Pulse, or DME pulse pair.




Figure 3.1.3.2.1 – TTG-7000 Transponder Test (Single Interrogation) Menu

Diagram Item	Softkey	Function
1	Yes	Test Mode Allows selection single interrogation mode, double interrogations, interrogation table, block interrogations, or interrogation with CW.
2	Yes	Interrogation Type Allows selection of interrogation of any of the following: Mode A, Mode C, Mode A All-Call, Mode C All-Call, Mode A/Mode S All-Call, Mode C/Mode S All-Call,

Diagram Item	Softkey	Function
		Mode S, P1-P2, Pulse, DME pulse pair, or Alternating Mode A/C.
3	Yes	Pulse Repetition Frequency (PRF) 1 to 10000 Hz
4	Yes	Power Range from -20 to -90 dBm in 1 dB steps.
5	Yes	Frequency
6	Yes	Measurement Pulse
7	Yes	Antenna Selection Top or Bottom
8	Yes	Information Section Provides to the user % reply, Mode A code, Mode C Altitude, Mode S reply
9	No	Measurement Pulse Scope illustration
	Yes	Load Loads a saved transponder test.
	Yes	Save Saves current test setup to a CSV file.
	Yes	Reset Resets the current screen to default values.
	Yes	Single Interrogation Mode Allows modifying the selected single interrogation type parameters (I.E. pulse spacing, pulse width ...).
	Yes	Tx Start/Stop Transmissions
	Yes	Instrument Settings Cable Loss (Cable loss on top antenna). Cable Loss Bottom (Cable loss on bottom antenna). Suppression Output On/Off Interference Pulse On/Off (Single, Double, and Interrogation Table Modes). Interference Pulse only on Top antenna port. Burst On/Off (Interrogation Table Mode Only)
	Yes	Interference Pulse Reset (Default interference pulse parameters). Pulse Spacing Start (-14.975 to 393 microsecond from interrogation P1). Interference Pulse P2 On/Off Interference Pulse P2 Spacing (0 to 400 microseconds). Pulse Width (0 to 1.95 microseconds) Pulse Level CAL, VAR, or OFF. Variable range +9 to -19 dB.

Diagram Item	Softkey	Function
		All signals above -20 dBm are limited to -20 dBm.
	Yes	Receiver Summary Provides squitter rates and data for common Transponder squitters.

3.1.3.3. Transponder Mode A Menu

Figure 3.1.3.3.1 illustrates the TTG-7000 Transponder Mode A Menu. The Transponder Mode A Menu allows the user to setup the test set for Mode A interrogations.




Figure 3.1.3.3.1 – Transponder Mode A Menu

Diagram Item	Softkey	Function
1	Yes	Interrogation mode
2	Yes	PRF Range 1-10000 Hz.
3	Yes	Power. Range -20 to -90 dBm in 1 dB steps.
4	Yes	Pulse Spacing. P1-P2 (0.05 to 3.95 microseconds). P1-P3 (6.05 to 9.95 microseconds). Spacing steps in 0.025 microseconds.
5	Yes	Pulse Width. 0 to 1.950 microseconds.

Diagram Item	Softkey	Function
		Steps in 0.025 microsecond.
6	Yes	Pulse Level. (CAL, VAR, OFF). Variable range +9 to -19 dB. All signals above -20 dBm are limited to -20 dBm.
7	Yes	Bottom settings. Time deviation +/- 1.0 microseconds in 0.025 microsecond steps. Power deviation +/- 20 dB in 1 dB steps. High end limit -20 dBm.
8	Yes	SLS On/Off

3.1.3.4. Transponder Mode C Menu

Figure 3.1.3.4.1 illustrates the TTG-7000 Transponder Mode C Menu. The Transponder Mode C Menu allows the user to setup the test set for Mode C interrogations.




Figure 3.1.3.4.1 – Transponder Mode C Menu

Diagram Item	Softkey	Function
1	Yes	Interrogation mode
2	Yes	PRF Range 1-10000 Hz.
3	Yes	Power. Range -20 to -90 dBm in 1 dB steps.
4	Yes	Pulse Spacing. P1-P2 (0.05 to 3.95 microseconds). P1-P3 (19.05 to 22.95 microseconds). Spacing steps in 0.025 microseconds.
5	Yes	Pulse Width. 0 to 1.950 microseconds.

Diagram Item	Softkey	Function
		Steps in 0.025 microsecond.
6	Yes	Pulse Level. (CAL, VAR, OFF). Variable range +9 to -19 dB. All signals above -20 dBm are limited to -20 dBm.
7	Yes	Bottom settings. Time deviation +/- 1.0 microseconds in 0.025 microsecond steps. Power deviation +/- 20 dB in 1 dB steps. High end limit -20 dBm.
8	Yes	SLS On/Off

3.1.3.5. Transponder Mode A All-Call Menu

Figure 3.1.3.5.1 illustrates the TTG-7000 Transponder Mode A All-Call Menu. The Transponder Mode A All-Call Menu allows the user to setup the test set for Mode A All-Call interrogations.




Figure 3.1.3.5.1 – Transponder Mode A All-Call Menu

Diagram Item	Softkey	Function
1	Yes	Interrogation mode
2	Yes	PRF Range 1-10000 Hz.
3	Yes	Power. Range -20 to -90 dBm in 1 dB steps.
4	Yes	Pulse Spacing. P1-P2 (0.05 to 3.95 microseconds). P1-P3 (6.05 to 9.95 microseconds). P3-P4 (0.05 to 3.95 microseconds) Spacing steps in 0.025 microseconds.

Diagram Item	Softkey	Function
5	Yes	Pulse Width. 0 to 1.950 microseconds. (P1,P2, and P3) 0 to 2.5 microseconds. (P4) Steps in 0.025 microsecond.
6	Yes	Pulse Level. (CAL, VAR, OFF). Variable range +9 to -19 dB. All signals above -20 dBm are limited to -20 dBm.
7	Yes	Bottom settings. Time deviation +/- 1.0 microseconds in 0.025 microsecond steps. Power deviation +/- 20 dB in 1 dB steps. High end limit - 20 dBm.
8	Yes	SLS On/Off

3.1.3.6. Transponder Mode C All-Call Menu

Figure 3.1.3.6.1 illustrates the TTG-7000 Transponder Mode C All-Call Menu. The Transponder Mode C All-Call Menu allows the user to setup the test set for Mode C All-Call interrogations.




Figure 3.1.3.6.1 – Transponder Mode C All-Call Menu

Diagram Item	Softkey	Function
1	Yes	Interrogation mode
2	Yes	PRF Range 1-10000 Hz.
3	Yes	Power. Range -20 to -90 dBm in 1 dB steps.
4	Yes	Pulse Spacing. P1-P2 (0.05 to 3.95 microseconds). P1-P3 (20.05 to 22.95 microseconds). P3-P4 (0.05 to 3.95 microseconds) Spacing steps in 0.025 microseconds.

Diagram Item	Softkey	Function
5	Yes	Pulse Width. 0 to 1.950 microseconds. (P1,P2, and P3) 0 to 2.5 microseconds. (P4) Steps in 0.025 microsecond.
6	Yes	Pulse Level. (CAL, VAR, OFF). Variable range +9 to -19 dB. All signals above -20 dBm are limited to -20 dBm.
7	Yes	Bottom settings. Time deviation +/- 1.0 microseconds in 0.025 microsecond steps. Power deviation +/- 20 dB in 1 dB steps. High end limit - 20 dBm.
8	Yes	SLS On/Off

3.1.3.7. Transponder Mode A/Mode S All-Call Menu

Figure 3.1.3.7.1 illustrates the TTG-7000 Transponder Mode A/Mode S All-Call Menu. The Transponder Mode A/Mode S All-Call Menu allows the user to setup the test set for Mode A/Mode S All-Call interrogations.




Figure 3.1.3.7.1 – Transponder Mode A/Mode S All Call Menu

Diagram Item	Softkey	Function
1	Yes	Interrogation mode
2	Yes	PRF Range 1-10000 Hz.
3	Yes	Power. Range -20 to -90 dBm in 1 dB steps.
4	Yes	Pulse Spacing. P1-P2 (0.05 to 3.95 microseconds). P1-P3 (6.05 to 9.95 microseconds). P3-P4 (0.05 to 3.95 microseconds) Spacing steps in 0.025 microseconds.

Diagram Item	Softkey	Function
5	Yes	Pulse Width. 0 to 1.950 microseconds. (P1,P2, and P3) 0 to 2.5 microseconds. (P4) Steps in 0.025 microsecond.
6	Yes	Pulse Level. (CAL, VAR, OFF). Variable range +9 to -19 dB. All signals above -20 dBm are limited to -20 dBm.
7	Yes	Bottom settings. Time deviation +/- 1.0 microseconds in 0.025 microsecond steps. Power deviation +/- 20 dB in 1 dB steps. High end limit - 20 dBm.
8	Yes	SLS On/Off

3.1.3.8. Transponder Mode C/Mode S All-Call Menu

Figure 3.1.3.8.1 illustrates the TTG-7000 Transponder Mode C/Mode S All-Call Menu. The Transponder Mode C/Mode S All-Call Menu allows the user to setup the test set for Mode C/Mode S All-Call interrogations.




Figure 3.1.3.8.1 – Transponder Mode C/Mode S All-Call Menu

Diagram Item	Softkey	Function
1	Yes	Interrogation mode
2	Yes	PRF Range 1-10000 Hz.
3	Yes	Power. Range -20 to -90 dBm in 1 dB steps.
4	Yes	Pulse Spacing. P1-P2 (0.05 to 3.95 microseconds). P1-P3 (19.05 to 22.95 microseconds). P3-P4 (0.05 to 3.95 microseconds)

Diagram Item	Softkey	Function
		Spacing steps in 0.025 microseconds.
5	Yes	Pulse Width. 0 to 1.950 microseconds. (P1,P2, and P3) 0 to 2.5 microseconds. (P4) Steps in 0.025 microsecond.
6	Yes	Pulse Level. (CAL, VAR, OFF). Variable range +9 to -19 dB. All signals above -20 dBm are limited to -20 dBm.
7	Yes	Bottom settings. Time deviation +/- 1.0 microseconds in 0.025 microsecond steps. Power deviation +/- 20 dB in 1 dB steps. High end limit - 20 dBm.
8	Yes	SLS On/Off

3.1.3.9. Transponder Mode S Menu

Figure 3.1.3.9.1 illustrates the TTG-7000 Transponder Mode S Menu.




Figure 3.1.3.9.1 – Transponder Mode S Menu

Diagram Item	Softkey	Function
1	Yes	Interrogation mode
2	Yes	PRF. Range 1-10000 Hz.
3	Yes	Power. Range -20 to -90 dBm in 1 dB steps.
4	Yes	Pulse Spacing. P1-P2 (1 to 3 microseconds). P1-P6 (1.55 to 5.45 microseconds). P1-SPR (3.75 to 5.75 microseconds). P1-P5 (2.4 to 6.3 microseconds). Spacing steps in 0.025 microseconds.
5	Yes	Pulse Width. P1 and P2 (0 to 1.950 microseconds).

Diagram Item	Softkey	Function
		The last 0.5 microsecond of P6 (0 to 1.950 microseconds). P5 (0.2 to 1.950 microseconds). Steps in 0.025 microseconds.
6	Yes	Pulse Level. CAL, VAR, or OFF. Variable range +9 to -19 dB. All signals above -20 dBm are limited to -20 dBm. P5 Only
7	Yes	Bottom settings. Time deviation +/- 1.0 microseconds in 0.025 microsecond steps. Power deviation +/- 20 dB in 1 dB steps. Upper end limited to -20 dBm.
8	Yes	Interrogation
9	Yes	SLS On/Off

3.1.3.10. Transponder Test (Double Interrogation Mode)

Figure 3.1.3.10.1 illustrates the TTG-7000 Transponder Test Menu in Double Interrogation Mode. The Transponder Test Menu allows the user to setup the TTG-7000 to transmit a double interrogation.




Figure 3.1.3.10.1 – TTG-7000 Transponder Test (Double Interrogation) Menu

Diagram Item	Softkey	Function
1	Yes	Test Mode Allows selection single interrogation mode, double interrogations, interrogation table, block interrogations, or interrogation with CW.
2	Yes	Double Interrogation Table Illustrates the two interrogations selected for transmission.
3	Yes	Measurement Pulse
4	Yes	Antenna Selection Top or Bottom

Diagram Item	Softkey	Function
5	Yes	Information Section Provides to the user % reply, Mode A code, Mode C Altitude, Mode S reply
6	No	Measurement Pulse Scope illustration
	Yes	Load Loads a saved transponder test.
	Yes	Save Saves current test setup to a CSV file.
	Yes	Reset Resets the current screen to default values.
	Yes	Double Interrogation Allows modifying the double interrogation parameters.
	Yes	Tx Start/Stop Transmissions
	Yes	Instrument Settings Cable Loss (Cable loss on top antenna). Cable Loss Bottom (Cable loss on bottom antenna). Suppression Output On/Off Interference Pulse On/Off (Single, Double, and Interrogation Table Modes). Interference Pulse only on Top antenna port. Burst On/Off (Interrogation Table Mode Only)
	Yes	Interference Pulse Reset (Default interference pulse parameters). Pulse Spacing Start (-14.975 to 393 microsecond from interrogation P1). Interference Pulse P2 On/Off Interference Pulse P2 Spacing (0 to 400 microseconds). Pulse Width (0 to 1.95 microseconds) Pulse Level CAL, VAR, or OFF. Variable range +9 to -19 dB. All signals above -20 dBm are limited to -20 dBm.
	Yes	Receiver Summary Provides squitter rates and data for common Transponder squitters.

Figure 3.1.3.10.2 illustrates the menu for setting the parameters for a double interrogation. Both messages will be transmitted on the top antenna. To modify the parameters of any of the messages select the message and use the softkeys to the right.




Figure 3.1.3.10.2 – Double Interrogation Parameter Menu

Diagram Item	Softkey	Function
	Yes	Double Settings P1 – P1 Spacing (0 to 400 microseconds). Interlace Interrogation On/Off Interlace Ratio (1:1 to 1:1000). I.E. 1:4 ratio means that the TTG will transmit a second interrogation every fourth PRF period.
	Yes	Pulse Settings Will open the menu to change the pulse and spacing parameters for the selected transmission.
	Yes	Mode Allows selection of interrogation of any of the following: Mode A, Mode C, Mode A All-Call, Mode C All-Call, Mode A/Mode S All-Call, Mode C/Mode S All-Call,

Diagram Item	Softkey	Function
		Mode S, P1-P2, Pulse, DME pulse pair, or Alternating Mode A/C.
	Yes	PRF 1 to 10000 Hz
	Yes	Power Level -20 to -90 dBm.
	Yes	Frequency
	Yes	PRF Sync Provides mechanism to sync or unsync the PRF of the first transmission with the second. This softkey is available for P1-P2, Pulse or DME interrogations.
	Yes	Sync % reply and information sync.

3.1.4 UAT Menu

Figure 3.1.4.1 illustrates the TTG-7000 UAT Menu. The UAT Menu allows the user to select between the Settings, Receiving Station, Receiver, or Scenario menus for UAT testing.




Figure 3.1.4.1 – UAT Menu

Diagram Item	Softkey	Function
	Yes	Settings
	Yes	Receiving Station
	Yes	Receiver Menu
	Yes	Scenario

3.1.4.1. UAT Settings

Figure 3.1.4.1.1 illustrates the TTG-7000 UAT Settings Menu. The UAT Settings Menu allows the user to configure the Transmitter, Receiver, and Antenna Simulator modules within the test set for UAT tests. This menu is mainly used for testing and troubleshooting of the TTG-7000. For UAT unit testing, this menu should only be used to set the individual RF generator frequencies.




Figure 3.1.4.1.1 – UAT Settings Menu

Diagram Item	Softkey	Function
1	Yes	<p>OEM</p> <p>Allows the user to select the TCAS system OEM. The antenna resistors are set according to OEM selection. Also the calibration tables to emulate the bearing of intruders are loaded according to the OEM selection. OEM selections are Honeywell Directional, Honeywell Omni, Collins Phase Directional, Collins Phase Omni, ACSS Directional, ACSS Omni, Collins Magnitude</p>

Diagram Item	Softkey	Function
		Directional, Collins Magnitude Omni, Garmin or Avidyne.
2	Yes	Receiver Path Allows the user to select which port to connect the Top/Bottom Receiver. Selections available are Rx T1/B1, Rx T2/B2, Rx T3/B3, Rx T4/B4, Chamber, or Combine.
3	Yes	Modulation CW or Pulse
4	Yes	Tx Path Allows setting the Tx path to Top All Ports/Bottom All Ports/Single Port. For UAT, UAT #1 is set to B1 port and UAT #2 is set to B2 port.
5	Yes	Tx Power Allows the setting of the Transmitter power from -20 to -90 dBm in 1 dB steps.
6	Yes	Tx Frequency Allows the setting of the Transmitter frequency. Individual setting for each transmitter. Range from 962 to 1213 MHz in 0.1 MHz steps.
7	Yes	Generator On/Off
	Yes	Factory Setup Sets all hardware to default setting according to hardware configuration.

3.1.4.2. UAT Receiver Menu

Figure 3.1.4.2.1 illustrates the TTG-7000 UAT Receiver Menu. The UAT Receiver Menu allows the user to view the transmissions from an UAT system and the transmissions from the TTG-7000 test set.




Figure 3.1.4.2.1 – TTG-7000 UAT Receiver Menu

Diagram Item	Softkey	Function
1	No	Top section of the Receiver Menu illustrates the status of reception from either the TCAS system under test or from the test set. There is a LED associated for the ATCRBS Reply, DF Reply, ATCRBS Interrogation, and UF Interrogation for the TCAS System (Rx Group) and the test set (Tx Group). For UAT option, LEDs are shown in the Rx and Tx group.
2	No	Reception section shows the last 8 receptions. Lines in blue represent receptions from the TCAS system. Lines in green represent receptions from the test set.
	Yes	Capture

Diagram Item	Softkey	Function
		UUT DF TTG DF UUT UF TTG UF UUT ATCRBS Replies TTG ATCRBS Replies UUT ATCRBS Interrogation TTG ATCRBS Interrogation UUT UAT TTG UAT
	Yes	Display Display On/Off UTC Time On/Off UTC Source Update/Continuous Time Relative/Absolute Clear Frame Details Quantity to Show Refresh
	Yes	Datalogging Pause/Record Export Clear
	Yes	Filtered Masked Menu
	Yes	Highlight Masked Menu

When performing an export the TTG-7000 generates a SDF (Compact Database File) and exports the file to the selected file location. The operator can download from ATG's website a Reporting Tool that will display the contents of the SDF file and will allow the user to generate multiple CSV files from the exported data. Also all the DF17 position, velocity, and identification messages are decoded in the Reporting Tool.

3.1.4.3 UAT Receiving Station Menu

Figure 3.1.4.3.1 illustrates the TTG-7000 UAT Receiving Station Menu. The UAT Receiving Station allows the user to enter the Receiving Station position information.




Figure 3.1.4.3.1 – TTG-7000 UAT Receiving Station Menu

Diagram Item	Softkey	Function
1	Yes	Mode S Address
2	Yes	Latitude Range from -90 to 90 degrees.
3	Yes	Longitude Range from -180 to 180 degrees.
4	Yes	Altitude Range from -1000 to 65535 feet.
5	Yes	Heading Range from -180 to 180 degrees.

3.1.4.3. UAT Scenario Menu

Figure 3.1.4.4.1 illustrates the TTG-7000 UAT Scenario Menu. The UAT Scenario allows the user to define UAT scenario with static and dynamic targets.




Figure 3.1.4.4.1 – TTG-7000 UAT Scenario Menu

Diagram Item	Softkey	Function
1	Yes	Scenario Time. Range 0 to 6550 seconds.
2	Yes	Static Targets for UAT#1 defined and enabled.
3	Yes	Dynamic Targets for UAT#1 defined and enabled.
4	Yes	Dynamic Targets for UAT#2 defined and enabled.
5	Yes	Static Targets for UAT#1 defined and enabled.
		Capture Squitters and Data Logging. If enabled will clear log file when scenario starts and start capturing new messages.
		Static Test Mode.

Diagram Item	Softkey	Function
		Targets are active at the end of scenario time at their last position.
		Re-Compile After Load. Compiles all messages for the different targets after loading a saved file.
		UTC Time GPS. If enabled uses the UTC time from the GPS source input on external I/O BNC #3. If disabled, the Touchscreen provides the DSP and FPGA with the UTC time.
		UAT MSO Steps. The separation between UAT messages.
		Sweep Control for UAT#1. If enabled then the UAT messages will change every second by the sweep step until the MSO reaches the interval.
		Sweep Control for UAT#2. If enabled then the UAT messages will change every second by the sweep step until the MSO reaches the interval.

Note: When defining targets automatically the Touchscreen software starts at MSO 752 and spaces the targets at the specified MSO steps.

Note: In order to transmit UAT messages and the runtime to function after a start of scenario, the TTG-7000 needs the PPS signal from the GPS on external I/O #1 to function. User can also provide a 1 Hz signal on external I/O #1.

3.1.4.4.1 UAT Target Definition Menu

Figure 3.1.4.4.1.1 illustrates the TTG-7000 Target Definition Menu. The UAT Scenario allows the user to define UAT scenario with static and dynamic targets.




Figure 3.1.4.4.1.1 – TTG-7000 UAT Target Definition Menu [Payload 0 thru 10]

Diagram Item	Softkey	Function
1	Yes	Target Type. Static or Dynamic
2	Yes	Target Number
3	Yes	Payload Type. Payload 0 thru 10, Basic ADS-B, Long ADS-B, or Ground Uplink
4	Yes	Mode S Address
5	Yes	A/G State. Subsonic, Supersonic, Grounded, or Reserved
6	Yes	Altitude. Range from -1000 to 101350 feet.

Diagram Item	Softkey	Function
7	Yes	Latitude. Range +/-90 degrees
8	Yes	Longitude. Range +/- 180 degrees.
9	Yes	Vertical Speed. Range +/- 32704 feet/minute
10	Yes	Velocity. Range 0 to 1446 knots
11	Yes	Track. Range +/- 180 degrees
12	Yes	NIC
13	Yes	Uplink Feedback
14	Yes	Power. Range +1 to -98 dBm
15	Yes	Enable. If check, the target is enabled.
16	Yes	Start and Stop Times. For dynamic targets, the time when the target is operational.
17	Yes	MSO. The target MSO transmission slot.
18	Yes	Offset and Override. If override is disabled, the offset is calculated between the target latitude and longitude and the receiving station latitude and longitude. If override is enabled, the calculated offset is replace by the offset entered.
19	Yes	Address Qualifier
20	Yes	Vertical Velocity. Geometric or Barometric
21	Yes	Altitude Type. Barometric or Geometric
22	Yes	UTC Coupled.

Figure 3.1.4.4.1.2 illustrates the TTG-7000 UAT ADS-B Message Menu.




Figure 3.1.4.4.1.2 – TTG-7000 UAT ADS-B Message Menu

Diagram Item	Softkey	Function
1	No	Message Name, Payload and FEC
2	Yes	Payload Details Illustrates UAT Payload Fields Menu

Figure 3.1.4.4.1.3 illustrates the TTG-7000 UAT Payload Fields Menu.

Name	Value	Units	LSB	Description	Low	High	Invalid
Payload Type	0	N/A	1	Payload type	0	31	False
Address qualifier	0	N/A	1	Address qualifier	0	7	False
Address	000001	N/A	1	Address	000000	16777216	False
Latitude	0.000000	deg	2.1457672E	23 bit coded latitude	-90	90	False
Longitude	0.000000	deg	2.1457672E	24 bit coded latitude	-180	180	False
Altitude type	0	N/A	0	0 = Pressure Altitude and 1 = Geometric	0	1	False
Altitude	0	ft	25	12 bit coded (altitude-1000)	-1000	101350	False
NIC	Unknown	NM or m	0	Radius of containment	0	15	False
A/G state	0	N/A	0	0 = Subsonic, 1 =	0	3	False

UAT Payload Fields Menu

Local Remote

Payload Type

0

Address qualifier

0

Address

000001

Figure 3.1.4.4.1.3 – TTG-7000 UAT Payload Fields Menu

Figure 3.1.4.4.1.4 illustrates the TTG-7000 UAT Menu for either a Basic ADS-B or Long ADS-B. This menu allows the user to enter the hexadecimal data for the message and FEC portions of the ADS-B message.




Figure 3.1.4.4.1.4 – TTG-7000 UAT Target Definition Menu [Basic and Long ADS-B]

Diagram Item	Softkey	Function
1	Yes	Target Type. Static or Dynamic
2	Yes	Target Number
3	Yes	Payload Type. Payload 0 thru 10, Basic ADS-B, Long ADS-B, or Ground Uplink
4	Yes	ADS-B Message Data.
5	Yes	FEC Parity Data
6	Yes	Power. Range +1 to -98 dBm
7	Yes	Enable. If check, the target is enabled.
8	Yes	Start and Stop Times. For dynamic targets, the time when the target is operational.

Diagram Item	Softkey	Function
9	Yes	MSO. The target MSO transmission slot.
10	Yes	Offset and Override. If override is disabled, the offset is calculated between the target latitude and longitude and the receiving station latitude and longitude. If override is enabled, the calculated offset is replace by the offset entered.

Figure 3.1.4.4.1.5 illustrates the TTG-7000 UAT Menu for a Ground Uplink message.

The screenshot shows the TTG-7000 UAT Target Definition Menu for a Ground Uplink message. The interface is divided into a main configuration area on the left and a sidebar on the right. The main area contains fields for Type (Static), Number (1), Payload Type (Ground Uplink), Tx Channel (UAT RX1), UTC Coupled Condition (unchecked), Position Valid (checked), Application Data Valid (checked), Latitude (0.000000 deg), Longitude (0.000000 deg), Slot ID (0), TIS-B Site ID (0), and Power (-20.00 dBm). The sidebar contains a UATs Menu, Local/Remote selection, Type (Static), Target Number (1), Enable toggle (On), and Payload Type (Ground Uplink). Numbered callouts 1 through 14 point to specific elements in the interface.

Figure 3.1.4.4.1.5 – TTG-7000 UAT Target Definition Menu [Ground Uplink]

Diagram Item	Softkey	Function
1	Yes	Target Type. Static or Dynamic
2	Yes	Target Number
3	Yes	Payload Type. Payload 0 thru 10, Basic ADS-B, Long ADS-B, or Ground Uplink
4	Yes	UTC Coupled
5	Yes	Position Valid
6	Yes	Application Data Valid
7	Yes	Latitude
8	Yes	Longitude
9	Yes	Slot ID
10	Yes	TIS-B Site ID
11	Yes	Power. Range +1 to -98 dBm
12	Yes	Enable. If check, the target is enabled.

Diagram Item	Softkey	Function
13	Yes	Start and Stop Times. For dynamic targets, the time when the target is operational.
14	Yes	MSO. The target MSO transmission slot.
	Yes	Ground Uplink Message Illustrates Ground Uplink Message Menu.

3.2. How to ...

3.2.1. How to Change GPIB Address

1. Go to the TTG-7000 [Main Menu](#)
2. Press the **System Menu** softkey to display [System Menu](#).
3. Change the GPIB address using the **GPIB Address** combobox or select **GPIB Menu** softkey and then use the **GPIB Address** softkey. Once the address is changed, the new address is stored and will be used until changed again.

3.2.2. How to Change Transmitter Frequency

1. Go to the TTG-7000 [Main Menu](#)
2. Press the **TCAS** softkey to display [TCAS Main Menu](#).
3. Press the **Settings** softkey to display the [TCAS Settings Menu](#).
4. Change the frequency of the appropriate transmitter generator using the **Frequency** combobox or select **Signal Generator** softkey, appropriate transmitter generator softkey and then use the **Frequency** softkey.

3.2.3. How to Set a Scope Output

1. Go to the TTG-7000 [Main Menu](#)
2. Select the **System Menu** softkey to display [System Menu](#).
3. Change the output by using the **Scope 1 or Scope 2** combobox or using **Scope 1 or Scope 2** softkey.

3.2.4. How to Program DSP Software or FPGA Firmware

1. Go to the TTG-7000 [Main Menu](#)
2. Press the **System Menu** softkey to display [System Menu](#).
3. Press the **Software Update** softkey to display the [Software Update Menu](#).
4. Press the **Select** softkey to display the file dialog to select the configuration file that will be used for programming.

5. If all devices enabled in the configuration file are to be programmed, then press the **Execute** softkey to start programming. If some devices do not require reprogramming deselect the device under the Programming column and then press the **Execute** softkey to start programming.
6. During programming sequence the device being programmed will be highlighted in the table and a progress bar will be displayed in the lower section of the menu.
7. After programming is completed it is recommended to restart the system. To restart the system press the power switch allow power to turn off and press the power switch again to power up the test set.

3.2.5. How to Install the TTG-7000C RF Amplifier

1. Turn off power of the TTG-7000 by pressing the power switch on the front of the test set.
2. Connect the 25 pin ribbon cable provided with the TTG-7000C from the rear of the TTG-7000C Aux Control port to the TTG-7000 Aux Control port.
3. Match the RF ports on the front of the TTG-7000C with the RF ports on the front of the TTG-7000 using the RF cables provided with the TTG-7000C.
4. Connect the RF cables from chamber to the TTG-7000C RF ports on the rear.
5. Turn on power of the TTG-7000 by pressing the power switch on the front of the test set. The TTG-7000 provides power to the TTG-7000C, therefore the power indicator on the TTG-7000C should be illuminated once power is applied to the TTG-7000.

3.2.6. How to Enter Own Aircraft Information

1. Go to the TTG-7000 [Main Menu](#)
2. Press the **TCAS** softkey to display [TCAS Main Menu](#).
3. Press the **Own Aircraft** softkey to display the [TCAS Own Aircraft Menu](#).
4. Use the comboboxes or softkeys on the [TCAS Own Aircraft Menu](#) to enter the appropriate information.

3.2.7. How to Setup a Static ATCRBS Intruder

1. Go to the TTG-7000 [Main Menu](#)
2. Press the **TCAS** softkey to display [TCAS Main Menu](#).
3. Press the **Scenario** softkey to display the [TCAS Scenario Menu](#).
4. Use the **Scenario Time** combobox or softkey to enter the scenario time.

5. Set the number of static intruders to at least 1 using either the **Number of Static Intruders** combobox or softkey.
6. Press the **Intruders** softkey to edit the intruder information. Select Mode C in the **Intruder Mode** combobox or softkey to display the [Static Mode C Menu](#).
7. Use the controls on [Static Mode C Menu](#) to enter the information for your ATCRBS intruder.

Static Mode C Minimum Parameters		
Parameter	Default	Selection (Range)
Tx Channel	Gen A	Gen A, Gen C, or Gen D
Altitude	1000	-1000 to 126700 feet
Bearing	0	0 to 359 degrees
Range	0	0 to 160 Nmi
Latitude		-90 to 90 degrees
Longitude		-180 to 180 degrees
Reply Power	-20	-20 to -90 dBm (Low Power) 1 to -69 dBm (Hi Power)
Start at	0	0 to Scenario Duration
Stop at	Scenario Duration	0 to Scenario Duration
Enable	Enable	Enable/Disable
Reply	On	On/Off
Altitude Reporting	On	On/Off
WS1	0	0-255
WS2	0	0-255
Reply Antenna (WS1)	By Altitude	Bottom, Top, Both, By Altitude
Reply Antenna (WS2)	By Altitude	Bottom, Top, Both, By Altitude
Reply Quadrant (WS1)	Forward	Forward, Right, After, Left, Any Quadrant, By Location
Reply Quadrant (WS2)	Forward	Forward, Right, After, Left, Any Quadrant, By Location
Mode A Code	0000	0000-7777 (Octal)

Note: That for all intruders the location can be entered using range and bearing or latitude and longitude. If range and bearing is used the TTG-7000 will calculate the latitude and longitude of the intruder. If latitude and longitude is being used the TTG-7000 will calculate the range and bearing from the own aircraft.

8. When all the required information is entered press the **Back** softkey on the bottom of the softkey area to return to the [TCAS Scenario Menu](#).
9. To start the scenario use the **Scenario** softkey. Once the scenario has started the **Run Time** box on the top of the menu should be changing with the current scenario time.

10. If the scenario terminates, the **Scenario** softkey will return to the off position. If user wants to terminate the scenario before the total scenario time, change the **Scenario** softkey to the off position.

3.2.8. How to Setup a Dynamic ATCRBS Intruder

1. Go to the TTG-7000 [Main Menu](#)
2. Press the **TCAS** softkey to display [TCAS Main Menu](#).
3. Press the **Scenario** softkey to display the [TCAS Scenario Menu](#).
4. Use the **Scenario Time** combobox or softkey to enter the scenario time.
5. Set the number of dynamic intruders to at least 1 using either the **Number of Dynamic Intruders** combobox or softkey.
6. Press the **Intruders** softkey to edit the intruder information. Select Mode C in the **Intruder Mode** combobox or softkey to display the [Dynamic Mode C Menu](#).
7. Use the controls on [Dynamic Mode C Menu](#) to enter the information for your ATCRBS intruder. This screen is similar to the static, but allows the user to enter a velocity, vertical speed, and track direction.

Dynamic Mode C Minimum Parameters		
Parameter	Default	Selection (Range)
Tx Channel	Gen A	Gen A, Gen C, or Gen D
Altitude	1000	-1000 to 126700 feet
Bearing	0	0 to 359 degrees
Range	0	0 to 160 Nmi
Latitude		-90 to 90 degrees
Longitude		-180 to 180 degrees
Velocity	0	0 to 2000 knots
Vertical Speed	0	+/- 32576 ft/min
Track	0	-180 to 180 degrees
Reply Power	-20	-20 to -90 dBm (Low Power) 1 to -69 dBm (Hi Power)
Start at	0	0 to Scenario Duration
Stop at	Scenario Duration	0 to Scenario Duration
Enable	Enable	Enable/Disable
Reply	On	On/Off
Altitude Reporting	On	On/Off
WS1	0	0-255
WS2	0	0-255

Reply Antenna (WS1)	By Altitude	Bottom, Top, Both, By Altitude
Reply Antenna (WS2)	By Altitude	Bottom, Top, Both, By Altitude
Reply Quadrant (WS1)	Forward	Forward, Right, After, Left, Any Quadrant, By Location
Reply Quadrant (WS2)	Forward	Forward, Right, After, Left, Any Quadrant, By Location
Mode A Code	0000	0000-7777 (Octal)

Note: That for all intruders the location can be entered using range and bearing or latitude and longitude. If range and bearing is used the TTG-7000 will calculate the latitude and longitude of the intruder. If latitude and longitude is being used the TTG-7000 will calculate the range and bearing from the own aircraft.

- When all the required information is entered press the **Back** softkey on the bottom of the softkey area to return to the [TCAS Scenario Menu](#).
- To start the scenario use the **Scenario** softkey. Once the scenario has started the **Run Time** box on the top of the menu should be changing with the current scenario time.
- If the scenario terminates, the **Scenario** softkey will return to the off position. If user wants to terminate the scenario before the total scenario time, change the **Scenario** softkey to the off position.

3.2.9. How to Setup a Static Mode S Intruder

- Go to the TTG-7000 [Main Menu](#)
- Press the **TCAS** softkey to display [TCAS Main Menu](#).
- Press the **Scenario** softkey to display the [TCAS Scenario Menu](#).
- Use the **Scenario Time** combobox or softkey to enter the scenario time.
- Set the number of static intruders to at least 1 using either the **Number of Static Intruders** combobox or softkey.
- Press the **Intruders** softkey to edit the intruder information. Select Mode S TCAS Only in the **Intruder Mode** combobox or softkey to display the [Static Mode S Menu](#).
- Use the controls on [Static Mode S Menu](#) to enter the information for your Mode S intruder.

Static Mode S Minimum Parameters		
Parameter	Default	Selection (Range)
Tx Channel	Gen A	Gen A, Gen C, or Gen D
Altitude	1000	-1000 to 126700 feet
Bearing	0	0 to 359 degrees
Range	0	0 to 160 Nmi

Latitude		-90 to 90 degrees
Longitude		-180 to 180 degrees
Reply Power	-20	-20 to -90 dBm (Low Power) 1 to -69 dBm (Hi Power)
Reply Antenna	By Altitude	Bottom, Top, Both, Alternating, By Altitude
Squitter Power	-50	-20 to -90 dBm (Low Power) 1 to -69 dBm (Hi Power)
Squitter Antenna	Both	Top, Bottom, Both
Start at	0	0 to Scenario Duration
Stop at	Scenario Duration	0 to Scenario Duration
Enable	Enable	Enable/Disable
Reply	On	On/Off
Squitter	On	On/Off
Ground	Off	On/Off
Crosslink Capability	Off	On/Off
Mode S Address		0 – FFFFFFFF
Altitude Code Mode	Binary	Binary, Gilham
Reply Probability	1	0, 0.2, 0.4, 0.6, 0.8, 1
Squitter Probability	1	0, 0.2, 0.4, 0.6, 0.8, 1
Mode A Code	0000	0000-7777 (Octal)
CA	0	0-7
FS	0	0-7
DR	0	0-31
UM	0	0-63
SL	No TCAS Sensitivity Level	0-7
RI (AQ=0)	No on board TCAS	0-7
RI(AQ=1)	No Airspeed	0-7

Note: That for all intruders the location can be entered using range and bearing or latitude and longitude. If range and bearing is used the TTG-7000 will calculate the latitude and longitude of the intruder. If latitude and longitude is being used the TTG-7000 will calculate the range and bearing from the own aircraft.

- When all the required information is entered press the **Back** softkey on the bottom of the softkey area to return to the [TCAS Scenario Menu](#).
- To start the scenario use the **Scenario** softkey. Once the scenario has started the **Run Time** box on the top of the menu should be changing with the current scenario time.

10. If the scenario terminates, the **Scenario** softkey will return to the off position. If user wants to terminate the scenario before the total scenario time, change the **Scenario** softkey to the off position.

3.2.10. How to Setup a Dynamic Mode S Intruder

1. Go to the TTG-7000 [Main Menu](#).
2. Press the **TCAS** softkey to display [TCAS Main Menu](#).
3. Press the **Scenario** softkey to display the [TCAS Scenario Menu](#).
4. Use the **Scenario Time** combobox or softkey to enter the scenario time.
5. Set the number of dynamic intruders to at least 1 using either the **Number of Dynamic Intruders** combobox or softkey.
6. Press the **Intruders** softkey to edit the intruder information. Select Mode S TCAS Only the **Intruder Mode** combobox or softkey to display the [Dynamic Mode S Menu](#).
7. Use the controls on [Dynamic Mode S Menu](#) to enter the information for your Mode S intruder. This screen is similar to the static, but allows the user to enter a velocity, vertical speed, and track direction.

Dynamic Mode S Minimum Parameters		
Parameter	Default	Selection (Range)
Tx Channel	Gen A	Gen A, Gen C, or Gen D
Altitude	1000	-1000 to 126700 feet
Bearing	0	0 to 359 degrees
Range	0	0 to 160 Nmi
Latitude		-90 to 90 degrees
Longitude		-180 to 180 degrees
Velocity	0	0 to 2000 knots
Vertical Speed	0	+/- 32576 ft/min
Track	0	-180 to 180 degrees
Reply Power	-20	-20 to -90 dBm (Low Power) 1 to -69 dBm (Hi Power)
Reply Antenna	By Altitude	Bottom, Top, Both, Alternating, By Altitude
Squitter Power	-50	-20 to -90 dBm (Low Power) 1 to -69 dBm (Hi Power)
Squitter Antenna	Both	Top, Bottom, Both
Start at	0	0 to Scenario Duration

Stop at	Scenario Duration	0 to Scenario Duration
Enable	Enable	Enable/Disable
Reply	On	On/Off
Squitter	On	On/Off
Ground	Off	On/Off
Crosslink Capability	Off	On/Off
Mode S Address		0 – FFFFFFFF
Altitude Code Mode	Binary	Binary, Gilham
Reply Probability	1	0, 0.2, 0.4, 0.6, 0.8, 1
Squitter Probability	1	0, 0.2, 0.4, 0.6, 0.8, 1
Mode A Code	0000	0000-7777 (Octal)
CA	0	0-7
FS	0	0-7
DR	0	0-31
UM	0	0-63
SL	No TCAS Sensitivity Level	0-7
RI (AQ=0)	No on board TCAS	0-7
RI(AQ=1)	No Airspeed	0-7

Note: That for all intruders the location can be entered using range and bearing or latitude and longitude. If range and bearing is used the TTG-7000 will calculate the latitude and longitude of the intruder. If latitude and longitude is being used the TTG-7000 will calculate the range and bearing from the own aircraft.

8. When all the required information is entered press the **Back** softkey on the bottom of the softkey area to return to the [TCAS Scenario Menu](#).
9. To start the scenario use the **Scenario** softkey. Once the scenario has started the **Run Time** box on the top of the menu should be changing with the current scenario time.
10. If the scenario terminates, the **Scenario** softkey will return to the off position. If user wants to terminate the scenario before the total scenario time, change the **Scenario** softkey to the off position.

3.2.11. How to Setup a Static Mode S Extended Intruder

1. Go to the TTG-7000 [Main Menu](#)
2. Press the **TCAS** softkey to display [TCAS Main Menu](#).
3. Press the **Scenario** softkey to display the [TCAS Scenario Menu](#).
4. Use the **Scenario Time** combobox or softkey to enter the scenario time.

5. Set the number of static intruders to at least 1 using either the **Number of Static Intruders** combobox or softkey.
6. Press the **Intruders** softkey to edit the intruder information. Select Mode S Extended in the **Intruder Mode** combobox or softkey to display the [Static Mode S Extended Menu](#).
7. Use the controls on [Static Mode S Extended Menu](#) to enter the information for your Mode S Extended intruder.

Static Mode S Extended Minimum Parameters		
Parameter	Default	Selection (Range)
Tx Channel	Gen A	Gen A, Gen C, or Gen D
Altitude	1000	-1000 to 126700 feet
Bearing	0	0 to 359 degrees
Range	0	0 to 160 Nmi
Latitude		-90 to 90 degrees
Longitude		-180 to 180 degrees
Velocity	0	0 to 2000 knots
Vertical Speed	0	+/- 32576 ft/min
Track	0	-180 to 180 degrees
Reply Power	-20	-20 to -90 dBm (Low Power) 1 to -69 dBm (Hi Power)
Reply Antenna	By Altitude	Bottom, Top, Both, Alternating, By Altitude
Squitter Power	-50	-20 to -90 dBm (Low Power) 1 to -69 dBm (Hi Power)
Squitter Antenna	Both	Top, Bottom, Both
Start at	0	0 to Scenario Duration
Stop at	Scenario Duration	0 to Scenario Duration
Enable	Enable	Enable/Disable
Reply	On	On/Off
Squitter	On	On/Off
Ground	Off	On/Off
DO-260 Mode	DO-260	DO-260, DO-260A, DO-260B
Crosslink Capability	Off	On/Off
Mode S Address		0 – FFFFFFFF
Override Range Calculation	Off	On/Off
Altitude Code Mode	Binary	Binary, Gilham
Reply Probability	1	0, 0.2, 0.4, 0.6, 0.8, 1
Squitter Probability	1	0, 0.2, 0.4, 0.6, 0.8, 1
Mode A Code	0000	0000-7777 (Octal)

Identification Code	Static (STAxxx) xxx = intruder number	Up to 8 characters
Identification Type	1	1-4
Velocity Type	GroundSpeed Normal (1)	0-7
CA	0	0-7
FS	0	0-7
DR	0	0-31
UM	0	0-63
SL	No TCAS Sensitivity Level	0-7
RI (AQ=0)	No on board TCAS	0-7
RI(AQ=1)	No Airspeed	0-7
RI(DF=16)	No on board TCAS	0-15

Note: That for all intruders the location can be entered using range and bearing or latitude and longitude. If range and bearing is used the TTG-7000 will calculate the latitude and longitude of the intruder. If latitude and longitude is being used the TTG-7000 will calculate the range and bearing from the own aircraft.

8. When all the required information is entered press the **Back** softkey on the bottom of the softkey area to return to the [TCAS Scenario Menu](#).
9. To start the scenario use the **Scenario** softkey. Once the scenario has started the **Run Time** box on the top of the menu should be changing with the current scenario time.
10. If the scenario terminates, the **Scenario** softkey will return to the off position. If user wants to terminate the scenario before the total scenario time, change the **Scenario** softkey to the off position.

3.2.12. How to Setup a Dynamic Mode S Extended Intruder

1. Go to the TTG-7000 [Main Menu](#).
2. Press the **TCAS** softkey to display [TCAS Main Menu](#).
3. Press the **Scenario** softkey to display the [TCAS Scenario Menu](#).
4. Use the **Scenario Time** combobox or softkey to enter the scenario time.
5. Set the number of dynamic intruders to at least 1 using either the **Number of Dynamic Intruders** combobox or softkey.
6. Press the **Intruders** softkey to edit the intruder information. Select Mode S Extended the **Intruder Mode** combobox or softkey to display the [Dynamic Mode S Extended Menu](#).
7. Use the controls on [Dynamic Mode S Extended Menu](#) to enter the information for your Mode S Extended intruder.

Dynamic Mode S Extended Minimum Parameters		
Parameter	Default	Selection (Range)
Tx Channel	Gen A	Gen A, Gen C, or Gen D
Altitude	1000	-1000 to 126700 feet
Bearing	0	0 to 359 degrees
Range	0	0 to 160 Nmi
Latitude		-90 to 90 degrees
Longitude		-180 to 180 degrees
Velocity	0	0 to 2000 knots
Vertical Speed	0	+/- 32576 ft/min
Track	0	-180 to 180 degrees
Reply Power	-20	-20 to -90 dBm (Low Power) 1 to -69 dBm (Hi Power)
Reply Antenna	By Altitude	Bottom, Top, Both, Alternating, By Altitude
Squitter Power	-50	-20 to -90 dBm (Low Power) 1 to -69 dBm (Hi Power)
Squitter Antenna	Both	Top, Bottom, Both
Start at	0	0 to Scenario Duration
Stop at	Scenario Duration	0 to Scenario Duration
Enable	Enable	Enable/Disable
Reply	On	On/Off
Squitter	On	On/Off
Ground	Off	On/Off
Crosslink Capability	Off	On/Off
Mode S Address		0 – FFFFFFFF
Altitude Code Mode	Binary	Binary, Gilham
Reply Probability	1	0, 0.2, 0.4, 0.6, 0.8, 1
Squitter Probability	1	0, 0.2, 0.4, 0.6, 0.8, 1
Mode A Code	0000	0000-7777 (Octal)
CA	0	0-7
FS	0	0-7
DR	0	0-31
UM	0	0-63
SL	No TCAS Sensitivity Level	0-7
RI (AQ=0)	No on board TCAS	0-7
RI(AQ=1)	No Airspeed	0-7

Note: That for all intruders the location can be entered using range and bearing or latitude and longitude. If range and bearing is used the TTG-7000 will calculate the latitude and longitude of the intruder. If latitude and longitude is being used the TTG-7000 will calculate the range and bearing from the own aircraft.

8. When all the required information is entered press the **Back** softkey on the bottom of the softkey area to return to the [TCAS Scenario Menu](#).
9. To start the scenario use the **Scenario** softkey. Once the scenario has started the **Run Time** box on the top of the menu should be changing with the current scenario time.
10. If the scenario terminates, the **Scenario** softkey will return to the off position. If user wants to terminate the scenario before the total scenario time, change the **Scenario** softkey to the off position.

4. REMOTE CONNECTION (VNC)

Open Internet Browser (Internet Explorer, Safari), in the address field enter `http://IPAddress(TTG7000):5800`. Port 5800 is the VNC Viewer port. A VNC viewer will be downloaded into your PC or MAC. A security dialog could be shown similar to Figure 4.1. Select Run.

Once the VNC Viewer is running a screen similar to Figure 4.2 (VNC Viewer Connection Details) will be shown. Select OK.

A screen similar to Figure 4.3 (VNC Authentication) will be illustrated. All TTG7000 are setup with the password `atg` by default at the factory. Enter `atg` and press return. If the operator has changed the password of their TTG7000, then enter the new password.




Figure 4.1 – VNC Viewer Download




Figure 4.2 – VNC Viewer Connection Details




Figure 4.3 – VNC Authentication

Once the password has been authenticated, a VNC Viewer form (Figure 4.4) will be displayed with the current screen on the TTG7000. Use the PC's mouse and keyboard to navigate between screens and modify parameters on the TTG7000. To stop using the VNC Viewer just close the VNC Viewer form.





Figure 4.4 – TTG7000 TouchScreen Software on VNC Viewer

To establish a VNC remote connection from an IPAD or Smartphone, download a VNC app into the device. Enter the IP Address of the TTG7000. Enter the password and the TTG7000 screen will be displayed on your IPAD or Smartphone.


5. TEST CONFIGURATIONS

Transponder ATC/Mode S/ELS/EHS Test Configuration

Transponder ADS-B Out (1090ES) Test Configuration




TCAS/Hybrid Surveillance/ITP Version 0/1 Validation Test Configuration



TTG-7000 allows connecting a TCAS antenna to bottom/top antenna port and simulating targets on opposite port.



ADS-B In /CDTI Test Configuration



TCAS Coordinated RA Test Configuration

